


# Installation, Commissioning and Servicing instructions

Floor standing oil fired condensing combination boiler balanced flue

## Greenstar Heatslave II External 2022+ 12/18, 18/25 & 25/32

For fully pumped sealed central heating systems and mains pressure domestic hot water.  
These appliances are for use with Kerosene (Class C2) only.



## Contents

|          |  |           |          |  |           |
|----------|--|-----------|----------|--|-----------|
| <b>1</b> | <b>Key to symbols and safety instructions</b>    | <b>3</b>  | <b>6</b> | <b>Commissioning</b>   | <b>33</b> |
| 1.1      | Key to symbols                                   | 3         | 6.1      | Pre-commissioning checks-appliance   | 33        |
| 1.2      | General safety instructions                      | 3         | 6.2      | Filling the system   | 33        |
| <b>2</b> | <b>Installation regulations</b>                  | <b>4</b>  | 6.3      | Starting the appliance   | 34        |
| 2.1      | Complying with the building regulations          | 4         | 6.3.1    | Single pipe gravity feed systems:  | 34        |
| <b>3</b> | <b>Appliance information</b>                     | <b>5</b>  | 6.3.2    | Double pipe sub-gravity feed systems and single pipe suction lift with de-aerator: | 34        |
| 3.1      | General information                              | 5         | 6.3.3    | Burner head setting  | 35        |
| 3.2      | Technical data                                   | 5         | 6.3.4    | Boiler lockout   | 35        |
| 3.3      | Energy efficiency                                | 6         | 6.3.5    | Switching the appliance on/off   | 36        |
| 3.4      | Layout & components                              | 7         | 6.3.6    | Selecting Service Menus  | 37        |
| <b>4</b> | <b>Pre-Installation</b>                          | <b>8</b>  | 6.3.7    | Finish commissioning boiler checks   | 39        |
| 4.1      | Cleaning primary systems                         | 8         | 6.4      | Water treatment  | 40        |
| 4.2      | Mains supply                                     | 9         | 6.5      | Finishing commissioning - Appliance  | 41        |
| 4.2.1    | Electrical supply                                | 9         | 6.5.1    | Appliance guarantee  | 41        |
| 4.2.2    | Water supply                                     | 9         | <b>7</b> | <b>Service and spares</b>  | <b>42</b> |
| 4.2.3    | Oil supply                                       | 9         | 7.1      | Inspection and service   | 42        |
| 4.2.4    | Pipework   | 10        | <b>8</b> | <b>Fault finding and diagnosis</b>   | <b>47</b> |
| 4.2.5    | Boiler isolation valve                           | 11        | 8.1      | Status cause codes   | 47        |
| 4.3      | Water systems and pipework                       | 11        | 8.2      | Information menu   | 47        |
| 4.4      | Condensate pipework                              | 12        | 8.3      | Service menus  | 48        |
| 4.4.1    | Condensate disposal connections                  | 12        | 8.4      | Factory reset and fault codes  | 49        |
| 4.4.2    | Soak away  | 13        | 8.4.1    | Factory reset  | 49        |
| 4.5      | Pressure relief pipework                         | 14        | 8.4.2    | Locking or Blocking fault conditions   | 49        |
| 4.6      | Boiler locations and clearances                  | 14        | 8.4.3    | Cause and fault codes  | 50        |
| 4.7      | Flue gas system considerations                   | 15        | 8.5      | DHW function chart   | 51        |
| 4.7.1    | Combustion air quality                           | 15        | 8.6      | CH function chart  | 52        |
| 4.7.2    | Flue terminal positions                          | 15        | 8.7      | Protection functions   | 52        |
| 4.8      | Flue options                                     | 18        | 8.8      | Solar compatibility  | 53        |
| 4.8.1    | Cabinet mounted balanced horizontal flue options | 18        | 8.9      | Burner diagnostics mode  | 54        |
| 4.8.2    | Plume management                                 | 18        | 8.10     | Riello digital control boxes   | 54        |
| 4.8.3    | Plume management considerations                  | 19        | 8.10.1   | Control box LED codes  | 54        |
| <b>5</b> | <b>Installation</b>                              | <b>21</b> | 8.10.2   | Fault finding  | 55        |
| 5.1      | Unpacking the boiler                             | 21        | 8.11     | Flame sensing photocell  | 56        |
| 5.2      | Pipework and flue positions                      | 21        | 8.12     | Oil supply vacuum testing  | 56        |
| 5.3      | Boiler installation                              | 22        | 8.13     | Air pressure switch, flue overheat reset and tank overheat reset                   | 56        |
| 5.4      | Flue installation                                | 22        | 8.14     | Air pressure switch connections  | 57        |
| 5.4.1    | Flue Components                                  | 22        | 8.15     | System gassing   | 57        |
| 5.4.2    | Rear Flue options_ Greenstar - all models        | 22        | 8.16     | Oil appliance commissioning checklist  | 59        |
| 5.4.3    | Side Flue options - Heatslave II                 | 23        | 8.17     | Service interval record  | 60        |
| 5.4.4    | All flue options, final assembly                 | 24        |          |  |           |
| 5.4.5    | Terminal guard                                   | 25        |          |  |           |
| 5.4.6    | Flue damper installation                         | 25        |          |  |           |
| 5.4.7    | Installation notes                               | 25        |          |  |           |
| 5.4.8    | All flue options                                 | 25        |          |  |           |
| 5.5      | Combustion chamber                               | 25        |          |  |           |
| 5.6      | Pipework connections                             | 26        |          |  |           |
| 5.7      | Oil burner and pump                              | 27        |          |  |           |
| 5.8      | Refitting components                             | 28        |          |  |           |
| 5.9      | Electrical                                       | 29        |          |  |           |
| 5.10     | Electrical schematic                             | 31        |          |  |           |
| 5.11     | Weather compensation                             | 32        |          |  |           |

# 1 Key to symbols and safety instructions

## 1.1 Key to symbols

### Warnings

|  |   |
|--|---|
|  | Warnings in this document are identified by a warning triangle printed against a grey background. Keywords at the start of a warning indicate the type and seriousness of the ensuing risk if measures to prevent the risk are not taken. |
|--|---|

The following keywords are defined and can be used in this document:

- **NOTICE** indicates a situation that could result in damage to property or equipment.
- **CAUTION** indicates a situation that could result in minor to medium injury.
- **WARNING** indicates a situation that could result in severe injury or death.
- **DANGER** indicates a situation that will result in severe injury or death.

### Important information

|  |   |
|--|---|
|  | This symbol indicates important information where there is no risk to people or property. |
|--|---|

### Additional symbols

| Symbol | Explanation                                     |
|--------|---|
| ▶      | Steps in an action sequence                     |
| →      | Cross-reference to another part of the document |
| •      | List entry                                      |
| –      | List entry (second level)                       |

Table 1

### Abbreviations used in this manual

|        |   |
|--------|---|
| ∅      | Diameter  |
| CH     | Central Heating   |
| DHW    | Domestic Hot Water  |
| DCW    | Domestic Cold water   |
| HE     | Heat Exchanger  |
| TRV    | Thermostatic Radiator Valve                                 |
| IP     | Ingress Protection  |
| CF     | Conventional Flue   |
| RS     | Room Sealed   |
| N/A    | Not Applicable  |
| SEDBUK | Seasonal Efficiency of Domestic Boilers in the UK           |
| OFTEC  | Oil Firing Technical Association for the Petroleum Industry |
| WRAS   | Water Regulations Advisory Scheme                           |
| IET    | Institution of Engineering and Technology                   |
| DWTA   | Domestic Water Treatment Association                        |
| LABC   | Local Authority Building Control Body                       |

Table 2

### Read these instructions before starting any installation

These instructions are applicable to the Worcester appliance model(s) stated on the front cover of this manual only and must not be used with any other make or model of appliance.

The instructions apply in the UK and Eire only and must be followed except for any statutory obligation.

This appliance must be installed by a competent person, failure to install correctly could lead to prosecution.

## 1.2 General safety instructions

These installation instructions are intended for heating engineers, plumbers, and electricians.

- ▶ Read any installation instructions (boiler, heating controls, etc.) carefully before starting the installation.
- ▶ Observe the safety instructions and warnings.
- ▶ Observe national and regional regulations, technical rules and guidelines.
- ▶ Record all work carried out.

### Oil fumes or leaks from the appliance

If you smell oil fumes, observe the following rules.

- ▶ Extinguish any naked flames
- ▶ Isolate the electrical supply
- ▶ Isolate the fuel supply to the boiler
- ▶ Rectify the fault

### Health and safety

The appliance contains no asbestos and no substances have been used in the construction process that contravene the COSHH Regulations (Control of Substances Hazardous to Health Regulations).

Where applicable, the CE mark indicates compliance with relative EU Directives.

### Combustible and corrosive materials

Do not store or use any combustible materials (paper, thinners, paints etc.) inside or within the vicinity of the appliance.

The combustion air must be kept clear of chemically aggressive substances which can corrode the appliance and invalidate any warranty.

### Handling instructions and guidelines

It is advised that more than one person is involved in the transfer of the packaged appliance from the van to the point of installation.

It is advised that no attempt should be made to move the packaged appliance without the use of a suitable truck.

At all times the correct method for handling heavy objects should be strictly observed.

- ▶ Lift only a manageable weight, or ask for help.
- ▶ When lifting, bend the knees, and keep the back straight and feet apart.
- ▶ Do not lift and twist at the same time.
- ▶ Lift and carry items close to the body.
- ▶ Wear protective clothing and gloves to protect from any sharp edges.

### Intended use

This boiler must only be used as a heat appliance in a heating system for domestic purposes.

Any other use is considered inappropriate. Any damage that results from such use is excluded from liability.

### Appliance operation

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge, if they have been given supervision or instruction concerning the use of the appliance, in a safe way, and understand the hazards involved.

Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

### Installation, commissioning and servicing

Installation, commissioning and servicing must only be carried out by a competent registered engineer.

- ▶ Only use original spares.
- ▶ Advise the user to have the system regularly serviced by a competent, qualified engineer (such as OFTEC registered personnel) using approved spares, to help maintain the economy, safety and reliability of the appliance.

### Fitting and Modification

Fitting the appliance and any controls to the appliance may only be carried out by a competent engineer in accordance with these instructions and the relevant Installation Regulations.

Flue systems must not be modified in any way other than as described in the fitting instructions.

Any misuse or unauthorised modifications to the appliance, flue or associated components and systems could invalidate the warranty. The manufacturer accepts no liability arising from any such actions, excluding statutory rights.

### Electrical work

Electrical work must only be carried out by a qualified electrician.

- ▶ Before starting electrical work:
  - Isolate the mains electrical supply and secure against unintentional re-connection.
  - Check for zero potential.
- ▶ Also observe connection diagrams of other system components.

### Handover to the user

When handing over, instruct the user how to operate the heating system and inform them about its operating conditions.

- ▶ Explain how to operate the heating system and draw the user's attention to any safety-relevant action.
- ▶ Explain that modifications and repairs must only be carried out by an authorised contractor.
- ▶ Advise the user to have the system serviced annually by a competent, qualified engineer, such as an OFTEC registered engineer.
- ▶ Leave the installation instructions with the completed commissioning form with the homeowner.

## 2 Installation regulations

### 2.1 Complying with the building regulations

This heating appliance forms part of the controlled services for the building. It is law that all controlled services for buildings must comply with building regulations. You must be able to satisfy your Local Authority Building Control Body (LABC) that the work carried out concerning the installation and commissioning of this heating appliance has been carried out to a satisfactory standard.

OFTEC operate a competent persons scheme and registered installers are able to certify that their work complies with building regulations. Under the scheme;

- OFTEC must be informed about every installation.
- OFTEC will issue a building regulations compliance certificate to the householder and will notify the LABC.

OFTEC provide controlled document forms CD10 and CD11 for use during installation and commissioning respectively.

Other organisations operate self-certification schemes e.g. NAPIT and BESCA Ltd. and it may be possible for installers who are members of these organisations to self certify their work.

Alternatively you must submit a building control notice to the LABC before installing any boiler. The LABC will then arrange regular inspection visits during the work to ensure that the installation complies with the regulations.

### Installation

Failure to install appliances correctly could lead to prosecution.

The appliance should be installed by a competent person. The person installing the appliance should be aware of the Health and Safety at Work Act and take appropriate action to ensure that the regulations are adhered to. In order to give optimum efficiency and trouble free operation the appliance must be commissioned by a qualified OFTEC engineer.

The compliance with a British Standard does not, in itself, confer immunity from legal obligations. In particular the installation of this appliance must be in accordance with the relevant requirements of the following British Standards and regulations in respect of the safe installation of equipment:

|                  |   |
|------------------|---|
| BS 5410: part 1: | Code of practice for Liquid Fueled Boilers.   |
| BS 799: part 5:  | Specification for Oil Storage Tanks   |
| BS 7593:         | Code of Practice for treatment of water in domestic hot water central heating systems.  |
| BS 5449: part 1: | Specification for forced circulation hot water central heating for domestic premises.   |
| BS EN 12828:     | Heating systems in buildings.<br>Design for water-based heating systems   |
| BS 7291:         | Thermoplastic pipes and associated fittings for hot and cold water for domestic purposes and heating installations in buildings |
| BS 7074: part 1: | Application, selection and installation of expansion vessels and ancillary equipment for sealed water systems.                  |
| BS 1254-2:       | Copper and copper alloys plumbing fittings part 2: Fittings with compression ends for use with copper tubes.                    |
| BS 7671:         | IET Wiring Regulations, current edition.  |
| BS 1362:         | Specification for general purpose fuse links for domestic and similar purposes.   |

The Building Regulations Part G, Part J and L1 England and Wales; Part F, Part G and Part J Section III Scotland; Part L and Part F Northern Ireland.

Local water company bye-laws.

The Control of Pollution (Oil) Regulations.

OFTEC Standards.

Where no specific instruction is given, reference should be made to the relevant codes of practice.

### Installations in Eire (Republic of Ireland)

The Installation must be performed by a competent and suitably trained person in accordance with the following Eire regulations.

Current Building Regulations - Republic of Ireland

ETCI rules for electrical installation

### For further guidance see

OFTEC Technical book three - Regional requirements: Republic of Ireland

### 3 Appliance information

#### 3.1 General information

##### Standard package




Fig. 1 Standard package

- [A] Floor standing oil fired condensing combination boiler for sealed central heating and mains fed domestic hot water.
- [B] Flue damper
- [C] Literature pack
- [D] 100mm Ø services duct.
- [E] Balanced flue kit
- [F] Utility key
- [G] Mains supply socket
- [H] ErP label

##### Check List (Literature pack)

| Item   | Qty |
|--|-----|
| Greenstar Heatslave II External Installation/ Servicing Instructions | 1   |
| Instructions   | 1   |
| Hardware Pack  | 1   |

#### 3.2 Technical data

| Description   | Units           | 12/18 | 18/25 | 25/32 |
|---|-----------------|-------|-------|-------|
| <b>Central heating</b>  |                 |       |       |       |
| Primary water capacity (total)  | litres          | 62    | 63    | 64    |
| Available pump head (20°C difference) at max. output                          | metres water    | 4.7   | 4.0   | 4.2   |
| Max. permissible system operating pressure in accordance with WRAS guidelines | bar             | 2.5   | 2.5   | 2.5   |
| Flow restrictor   | colour          | Lime  | Beige | Grey  |
| <b>Domestic Hot Water</b>   |                 |       |       |       |
| Maximum flow rate (± 15%)   | litres/min      | 15    | 18    | 22    |
| Minimum inlet pressure (dynamic) for maximum flow rate                        | bar             | 1.5   | 1.2   | 1.6   |
| Maximum hot water temperature rise for 90 litres draw off (@max flow rate)    | °C              | 40    | 40    | 40    |
| <b>Flue</b>   |                 |       |       |       |
| Exit flue gas mass flow   | kg/hr           | 29    | 40    | 51    |
| <b>Pipework connections</b>   |                 |       |       |       |
| Fuel line (compression)   | mm              | 10    | 10    | 10    |
| CH flow   | mm              | 22    | 22    | 28    |
| CH return   | mm              | 22    | 22    | 28    |
| Water main inlet  | mm              | 15    | 15    | 15    |
| DHW outlet  | mm              | 22    | 22    | 22    |
| CH drain  | hose connection |       |       |       |
| Condensate (polypropylene)  | mm              | 21.5  | 21.5  | 21.5  |
| <b>Electrical</b>   |                 |       |       |       |
| Electrical power supply voltage   | AC...V          | 230   | 230   | 230   |
| Frequency   | Hz              | 50    | 50    | 50    |
| <b>Sensors &amp; Thermostats</b>  |                 |       |       |       |
| CH control range  | °C              | 50/82 | 50/82 | 50/82 |
| Slave tank control range  | °C              | 55/84 | 55/86 | 55/88 |
| Boiler manual reset overheat set point  | °C              | 105   | 105   | 105   |
| Flue manual reset overheat thermostat set point                               | °C              | 110   | 110   | 110   |
| Tank manual reset overheat thermostat set point                               | °C              | 95    | 95    | 95    |
| <b>General data</b>   |                 |       |       |       |
| Maximum hearth temperature  | °C              | <100  | <100  | <100  |
| SEDBUK 2009   | %               | 89.0  | 88.9  | 88.8  |
| SEDBUK 2005   | %               | 90.2  | 90.1  | 89.9  |
| Appliance protection rating   | IP              | 45    | 45    | 45    |
| Weight (excluding packaging)  | kg              | 151   | 154   | 158   |

### 3.3 Energy efficiency

The following product data satisfy the requirements of the EU Regulations No. 811/2013 and No. 812/2013 supplementing Directive 2010/30/EU.


| Product data   | Symbol             | Unit   | 7731600263   | 7731600264   | 7731600265   |
|--|--------------------|--------|--|--|--|
| Product type   | –                  | –      | Greenstar Heatslave II External <sup>2022+</sup> 12/18 | Greenstar Heatslave II External <sup>2022+</sup> 18/25 | Greenstar Heatslave II External <sup>2022+</sup> 25/32 |
| Condensing boiler  | –                  | –      | Yes  | Yes  | Yes  |
| Low temperature boiler   | –                  | –      | No   | No   | No   |
| B1 boiler  | –                  | –      | No   | No   | No   |
| Cogeneration space heater (CHP)                                      | –                  | –      | No   | No   | No   |
| Combination heater   | –                  | –      | Yes  | Yes  | Yes  |
| Rated heat output  | $P_{\text{rated}}$ | kW     | 18   | 25   | 32   |
| Seasonal space heating energy efficiency                             | $\eta_{\text{S}}$  | %      | 92   | 92   | 92   |
| Energy efficiency class  | –                  | –      | A  | A  | A  |
| <b>Useful heat output</b>  |                    |        |  |  |  |
| At rated heat output and high temperature regime <sup>1)</sup>       | $P_4$              | kW     | 18.2   | 25.1   | 32.9   |
| At 30% of rated heat output and low temperature regime <sup>2)</sup> | $P_1$              | kW     | 5.6  | 7.8  | 10.0   |
| <b>Useful efficiency</b>   |                    |        |  |  |  |
| At rated heat output and high temperature regime <sup>1)</sup>       | $\eta_4$           | %      | 91.8   | 91.9   | 91.5   |
| At 30% of rated heat output and low temperature regime <sup>2)</sup> | $\eta_1$           | %      | 98.5   | 97.8   | 97.3   |
| <b>Auxiliary electricity consumption</b>                             |                    |        |  |  |  |
| At full load   | $e_{\text{I,max}}$ | kW     | 0.165  | 0.159  | 0.150  |
| At part load   | $e_{\text{I,min}}$ | kW     | 0.053  | 0.049  | 0.047  |
| In standby mode  | $P_{\text{SB}}$    | kW     | 0.002  | 0.002  | 0.002  |
| <b>Other items</b>   |                    |        |  |  |  |
| Standby heat loss  | $P_{\text{stby}}$  | kW     | 0.166  | 0.159  | 0.161  |
| Ignition burner power consumption                                    | $P_{\text{ign}}$   | kW     | 0  | 0  | 0  |
| Emissions of nitrogen oxides   | NOx                | mg/kWh | 110  | 103  | 109  |
| Annual energy consumption  | $Q_{\text{HE}}$    | GJ     | 57   | 79   | 103  |
| Sound power level, indoors   | $L_{\text{WA}}$    | dB(A)  | N/A  | N/A  | N/A  |
| <b>Additional data for combination heaters</b>                       |                    |        |  |  |  |
| Declared load profile  | –                  | –      | XL   | XL   | XL   |
| Daily electricity consumption  | $Q_{\text{elec}}$  | kWh    | 0.210  | 0.176  | 0.199  |
| Annual electricity consumption                                       | AEC                | kWh    | 46   | 39   | 44   |
| Daily fuel consumption   | $Q_{\text{fuel}}$  | kWh    | 31.232   | 32.834   | 32.426   |
| Annual fuel consumption  | AFC                | GJ     | 25   | 26   | 26   |
| Water heating energy efficiency                                      | $\eta_{\text{wh}}$ | %      | 66   | 63   | 64   |
| Water heating energy efficiency class                                | –                  | –      | B  | B  | B  |

Table 3 Product data for energy consumption

- 1) High temperature regime means 60 °C return temperature at heater inlet and 80 °C feed temperature at heater outlet.
- 2) Low temperature means for condensing boilers 30 °C, for low-temperature boilers 37 °C and for other heaters 50 °C return temperature (at heater inlet).

### 3.4 Layout & components

The diagram below excludes the top, front and RH side casing panels.



6720821722-01.1Wo

Fig. 2 Boiler layout

**Legend:**

- [1] Flue overheat reset
- [2] Air pressure switch
- [3] Flue overheat thermostat phial
- [4] Air intake duct
- [5] Pressure relief valve
- [6] Heat exchanger flow pipe
- [7] Condensate drain pipe
- [8] Secondary heat exchanger drain
- [9] Condensate drain pipe
- [10] Condensate outlet
- [11] Condensate trap
- [12] Oil isolating valve
- [13] Base plate and drip tray
- [14] Combustion chamber access cover
- [15] Expansion vessel
- [16] Primary heat exchanger drain
- [17] Heatslave tank
- [18] Riello burner
- [19] Heatslave tank drain
- [20] Flue manifold cover
- [21] Flue gas sample point plug
- [22] Control box assembly
- [23] Service mode button
- [24] Heatslave tank temperature control knob
- [25] Diagnostic port (Service engineer only)
- [26] System pressure gauge
- [27] Central heating temperature control knob
- [28] LCD Display
- [29] Drain point
- [30] Heatslave tank overheat manual reset
- [31] Circulating pump
- [32] Diverter valve assembly
- [33] Automatic air vent
- [34] DHW flow turbine
- [35] Heatslave tank temperature sensor
- [36] DHW Heat exchanger
- [37] Mians inlet temperature sensor
- [38] DHW pressure relief valve
- [40] Primary heat exchanger manual air vent
- [41] Flow temperature sensor
- [42] Primary heat exchanger safety sensor
- [43] Secondary heat exchanger manual air vent
- [44] Secondary heat exchanger
- [45] Pressure relief valve

## 4 Pre-Installation

### 4.1 Cleaning primary systems



Before installation

- ▶ All the following Pre-Installation sections must be read and requirements met before starting boiler or flue installations.



**CAUTION:** Mains power

- ▶ Isolate the mains supplies before starting any work and observe all relevant safety precautions.



Protect the boiler

- ▶ Debris from the system can damage the boiler and reduce efficiency. Failure to comply with the guidelines for the use of water treatment with the appliance will invalidate the appliance warranty.
- ▶ It is recommended that a primary water cleanser is fitted to the system. Worcester offers a system filter that helps remove both magnetite and non-magnetic debris.

#### BEFORE CLEANING THE SYSTEM:

- ▶ **Ensure that the system and pipe work is in good working order.**
- ▶ **Where possible keep the existing boiler/circulating pump in place when flushing the system.**

#### FOLLOW THE GUIDANCE OF BS7593

Treatment of water in domestic hot water central heating and also the flushing guidelines below.

#### FLUSHING THE SYSTEM

- ▶ Fill the system with cold water and check for leaks.
- ▶ Open all drain cocks and drain the system.
- ▶ Close drain cocks and add a suitable flushing agent at the correct strength for the system conditions in accordance with the manufacturer's instructions.
- ▶ Circulate the flushing agent before the boiler is fired up.
- ▶ Run the boiler/system at normal operating temperature as directed by the manufacturer of the flushing agent.
- ▶ Drain and thoroughly flush the system to remove the flushing agent and debris.
- ▶ It may be necessary to use a power flushing machine to aid the cleansing procedure in some circumstances.
- ▶ Close the drain cocks and refill with fresh water and a suitable inhibitor.
- ▶ Vent any air from the boiler and system.

#### INHIBITOR

Add a suitable inhibitor or combined inhibitor/anti-freeze, if the system is exposed to freezing conditions, to the heating system in accordance with the DWTA code of practice and inhibitor manufacturer's guidelines.



**WARNING:** Sealing agents

- ▶ In cases where all attempts to find a system micro leak have failed, Worcester, Bosch Group supports the use of Fernox F4 leak sealer.

#### Water treatment products

Suitable water treatment products can be obtain from the following manufacturers:

|          |   |
|----------|---|
| ADEY     | 01242 546700 - <a href="http://www.adey.com">www.adey.com</a>                               |
| FERNOX   | 0330 100 7750 - <a href="http://www.fernox.com">www.fernox.com</a>                          |
| SENTINEL | 01928 704330 - <a href="http://www.sentinelprotects.com/uk">www.sentinelprotects.com/uk</a> |



### Artificially softened water

It is possible to have an ion exchange water softener fitted to the cold water system of the property. However, the boiler requires an untreated cold water connection taken from the mains supply, before the water softener, to the primary water filling point of the heating system.

Alternatively there are water softening/treatment devices that do not adjust or alter the pH levels of the water. With these devices it may not be necessary to provide an untreated water by-pass to the primary water filling point of the heat system.



Salt based, softened water must not be used to fill the central heating system.

## 4.2 Mains supply

### 4.2.1 Electrical supply

- Supply: 230V - 50 Hz
- Cable: PVC insulated 0.75mm<sup>2</sup> (24 x 0.2mm) temperature rated to 90°C.
- Circuit breaker incorporating earth leakage protection.
- External 5A fuse to BS1362.
- The appliance must be earthed.
- This appliance must not be connected to a three phase supply.
- Wiring must comply with the latest IET wiring regulations.
- It must be possible to isolate the appliance from the electrical supply with at least a 3mm contact separation in both poles supplying the appliance.
- Wiring between the appliance and the electrical supply must comply with IET wiring regulations and any local regulations that may apply for fixed wiring to a stationary appliance.
- Any system connected to the boiler must not have a separate electrical supply.

### 4.2.2 Water supply

The following are general requirements and if necessary the advice of the local water company should be sought before fitting the appliance.

- The appliance cold water supply should be the first connection off the water main where possible.
- The appliance will accept pre-heated hot water to a maximum of 60°C

### Mains water pressure



**NOTICE:** Boiler damage

- ▶ Non-return, back flow prevention devices (including those associated with water meters) fitted to the mains water supply can cause a pressure build up which could damage the boiler and other household appliances.

#### Minimum dynamic mains water pressure for maximum performance

|        |        |        |
|--------|--------|--------|
| 12/18  | 18/25  | 25/32  |
| 1.5bar | 1.2bar | 1.6bar |

- Maximum mains fed water pressure 10 bar. If necessary, fit a pressure reducing valve.
- Where the water main supply has a non-return, back flow prevention valve fitted, a mini expansion vessel (A) must be connected to the mains water inlet pipe (B) between the non-return valve (C) and the boiler (D) as shown in figure 3.




Fig. 3 Mains expansion vessel

- [A] Mini expansion vessel
- [B] Mains water inlet
- [C] Non return valve
- [D] Boiler

### Use in hard water areas

Normally there is no need for water treatment to prevent scale formation as the maximum temperature of the heat exchanger is limited by the electronic control circuit.

In areas where the temporary water hardness exceeds 200ppm, consideration may need to be given to the fitting of a scale prevention device. In such circumstances, the advice of the local water authority should be sought.

### 4.2.3 Oil supply



**NOTICE:** Contaminated oil supplies can damage the appliance.

Failure to ensure that the oil supply is clear of contaminants may invalidate the appliance warranty.

- ▶ Ensure the oil supply is free of contaminants and measures are taken to prevent contamination of the appliance.



**NOTICE:** Liquid fuel supply pipes should be provided with mains equipotential bonding in accordance with BS 7671.

- **This appliance is suitable for Kerosene (Class C2) only, no other fuel must be used.**
- Plastic or steel tanks should be installed to BS 5410. A steel tank should conform to BS 799: part 5 and have a slope of 1:24 away from the outlet with a sludge cock at the lower end.
- **Do not use galvanised steel tanks or pipework for the oil system.**
- **Do not use soldered joints on the oil supply pipework.**

### Single pipe gravity feed system

The oil storage tank [1] must be positioned so that the oil level does not exceed 4 metres above the level of the burner oil pump [9] and in addition the oil level must be at least 300mm above the oil pump [9]. Where the maximum oil level in the oil storage tank exceeds 4 metres, a head breaking device must be installed between the tank [1] and the burner oil pump [9].




Fig. 4 Single pipe feed

- [1] Oil storage tank
- [2] Full base (plastic tank)
- [3] Isolating valve
- [4] Oil strainer and water separator
- [5] Fire valve to BS 5410
- [6] External boiler casing
- [7] Oil filter (70µm max filtration size)
- [8] Fire valve sensor
- [9] Oil pump
- [10] Oil burner
- [11] Non-return valve
- [12] De-aerator
- [13] Appliance isolation valve

**i** All dimensions are in metres unless otherwise stated. The maximum pipe run figures are based on using copper pipe with an inside diameter of 2mm less than the outside diameter.

### Maximum pipe run for single pipe gravity feed system

| Head [M] | 10mmØ | 12mmØ | Head [M] | 10mmØ | 12mmØ |
|----------|-------|-------|----------|-------|-------|
| 0.5      | 12    | 30    | 2.5      | 62    | 100   |
| 1.0      | 25    | 69    | 3.0      | 74    | 100   |
| 1.5      | 37    | 91    | 3.5      | 87    | 100   |
| 2.0      | 49    | 100   | 4.0      | 99    | 100   |

### Double pipe sub-gravity fed system

Maximum suction height 3.5 metres. Non-return valves must be fitted to the inlet and return oil line between the oil pump [9] and oil storage tank [1].




Fig. 5 Double pipe feed

### Maximum pipe run for double pipe sub-gravity fed system

| Head [M] | 10mmØ | 12mmØ | Head [M] | 10mmØ | 12mmØ |
|----------|-------|-------|----------|-------|-------|
| 0        | 50    | 100   | 2.0      | 26    | 66    |
| 0.5      | 44    | 100   | 2.5      | 20    | 50    |
| 1.0      | 38    | 95    | 3.0      | 14    | 37    |
| 1.5      | 32    | 80    | 3.5      | 8     | 22    |

### Single pipe suction lift with de-aerator

Maximum suction height 3.5 metres. The oil tank [1] must be positioned below the oil pump [9]. Create an inlet and return loop between the de-aerator [12] and oil pump [9].

A non-return valve must be incorporated within the de-aerator or fitted to the oil line between the oil storage tank [1] and the de-aerator [12]. A top feed oil tank fitted with a de-aerator using an internal non-return valve should have any non-return valves fitted in the base of the tank to the suction line removed to assist purging air from the oil line.




Fig. 6 De-aerator feed

### Maximum pipe run for single pipe suction lift with de-aerator

| Head [M] | FUEL FLOW RATE  |               |                |                 |
|----------|-----------------|---------------|----------------|-----------------|
|          | 2.5kg/h<br>8mmØ | 5kg/h<br>8mmØ | 10kg/h<br>8mmØ | 10kg/h<br>10mmØ |
| 0        | 100             | 55            | 26             | 100             |
| 0.5      | 95              | 45            | 23             | 100             |
| 1.0      | 80              | 40            | 20             | 90              |
| 1.5      | 70              | 35            | 17             | 75              |
| 2.0      | 60              | 30            | 14             | 65              |
| 2.5      | 45              | 25            | 11             | 50              |
| 3.0      | 35              | 15            | 8              | 35              |
| 3.5      | 25              | 10            | 5              | 20              |

**i** The table and illustration above is a guide only and does not in any way override the de-aerator manufacturer's instructions

### 4.2.4 Pipework

**CAUTION:** Fire protection device  
 ▶ Under no circumstances should a combination isolating/fire valve be used as the sole fire protection device

- ▶ Use flexible hoses to connect to the oil pump [9].
- ▶ Lay the oil supply pipe as straight and level as possible to avoid air pockets and unnecessary friction losses. Route away from the boiler access door or other hot surfaces.
- ▶ Install a manual isolating valve [3] to the oil supply pipe, as close to the oil storage tank [1] as possible.
- ▶ Fit an oil strainer and water separator [4] to the oil supply pipe, near the oil storage tank. Fit an additional oil filter ([7], 70 µm max filtration size) close to the boiler, but not inside the boiler casing.

- ▶ Fit a fire valve in accordance with BS 5410. The fire valve [5] should be fitted externally to the building and appliance with the fire valve sensor [8] located within the appliance case. A fire valve with a shut off temperature of 85°C or higher must be fitted to avoid the possibility of a nuisance shut off. The fire valve must be a minimum of 1 metre from the appliance. A capillary type valve provides a neat and simple installation, or a fusible link or electrical system may be used.

**4.2.5 Boiler isolation valve**

- ▶ Use copper pipe of the correct diameter according to the information shown in oil supply sections , & .
  - If using soft copper pipe (R220) with a compression fitting, an insert must be used to prevent the pipe from collapsing or distorting when the fitting is tightened.
- ▶ Slide nut [1] and olive [5] onto the oil supply pipe [4].
- ▶ Slide insert [3] into the pipe.
- ▶ Offer the pipe to the fitting [2] and tighten the nut [1].




Fig. 7 Isolation valve bracket removed for clarity

- ▶ Use flexible hoses to connect to the oil pump.

**4.3 Water systems and pipework**



The boiler should not be allowed to operate with a return temperature of less than 30°C when the system is up to operating temperature.



Oil burners cannot modulate to accommodate a reduction in heating loads. If the heating load can be significantly reduced due to TRV's or zoning of the heating circuits, consideration should be given as to how short cycling of the burner could be prevented. Burner run times should remain greater than 2 minutes during normal operation. A buffer vessel or thermal store should be considered to prevent excessive short cycling of a single appliance, or a low loss header could be used to divide the heating duty between multiple lower output appliances.

**Primary system plastic pipework**

- Any plastic pipework used for the CH system must have a polymeric barrier, complying with BS 7921 and installed to BS 5955 with 1000mm (minimum) length of copper or steel pipe connected to the boiler.
- Plastic pipework used for underfloor heating must be correctly controlled with a thermostatic blending valve limiting the temperature of the circuits to approximately 50°C with 1000 mm (minimum) length of copper or steel pipe connected to the boiler, and a 20 K differential must be maintained at the appliance.

**Primary system/connections/valves**

- Do not use galvanised pipes or radiators.
- All system connections, taps and mixing valves must be capable of sustaining a pressure of 3 bar.
- Radiator valves should conform to BS 2767:10.

- All other valves should conform to BS 1010.
- An automatic bypass valve must be connected between the heating flow and return where TRVs are used on all radiators, fitted to give at least a 3 metre circuit when activated.
- Drain cocks are required at all the lowest points on the system.
- Air vents are required at all high points on the system.

**Sealed primary system**

- Where the system volume is more than 180 litres at 0.5 bar or exceeds 2.65 bar at maximum heating temperature an extra expansion vessel (B) must be fitted as close as possible to the appliance in the central heating return.
- Pressurise the extra expansion vessel (B) to the same figure as the expansion vessel (A) built into the appliance.




Fig. 8 Combi boiler sealed system layout

- [A] Expansion vessel
- [B] Extra expansion vessel
- [C] Automatic bypass valve
- [D] Drain cock
- [E] Appliance
- [L] Lockshield valve
- [R] Radiators
- [T] Thermostatic radiator valve TRV
- [U] To filling system

**Filling primary sealed systems**



**Filling the system**

- ▶ The system must not be filled with salt based, softened water.

- Filling the system must comply with the method shown in the figure below.
- The filling point must be at low level and must never be a permanent connection to the mains water supply.
- Filling loops must be WRAS approved.




Fig. 9

- [CV] Check valve
- [SV] Stop valve




Fig. 10

**Showers/Bidets:**

- If a shower head can be immersed in water or comes closer than 25mm from the top edge of a bath or shower tray spill over level then an anti-siphon device must be fitted to the shower hose. Only thermostatically controlled showers are suitable for use with this appliance.
- Bidets with direct hot & cold mains water can be used (with the approval of the local water authority) and must be the over rim flushing type with shrouded outlets to prevent the fitting of hand held sprays.

**Domestic hot water:****Plastic pipework**

- Any plastic pipework used for the DHW system must have a polymeric barrier, complying with BS 7921 and installed to BS 5955 with 1000mm (minimum) length of copper or stainless steel pipe connected to the boiler.
- Before installing plastic pipework, the pipe manufacturer's literature should be consulted.
- To prevent the temperature & pressure exceeding the limits advised by the pipe manufacturer, a pressure reducing valve must be used to prevent the incoming water pressure exceeding 3 bar (maximum). Also a mini expansion vessel must be fitted to absorb the expanding water and a blending valve set to 60°C must be fitted before the DHW plastic pipework.
- When selecting plastic pipework for use with domestic water supply, it should be ensured that it is compliant with all current local & national legislation & regulations, including building regulations part G, BS 7291 - 1,2 & 3: BS 8000 - 15 and information.

**General:**

- Taps and mixing valves must be capable of sustaining a pressure up to 10 bar in accordance with the Water Regulations as they will be operating at mains water pressure.
- Hot water temperature and flow rate are affected by the size and insulation of pipework making up the distribution system and are controlled by the hot water tap and the water main inlet pressure. A mixing valve can be fitted if a more permanent setting is required.
- If using more than one outlet at once causes water flow starvation, fit flow balancing valves or Ball-O-Fix valves to the appropriate outlets.

**4.4 Condensate pipework****NOTICE: Rainwater or external drain disposal**

Untreated condensate must not be allowed to flow into streams or rivers

- ▶ A rainwater down pipe or an external drain shall only be used for condensate disposal if the down pipe or external drain is connected to a combined foul and rainwater system
- ▶ Refer to BS 6798 for more information

**NOTICE: Grey water systems**

Contamination of recovered water

- ▶ Condensate disposal shall not be allowed into a grey water recovery system that is intended for re-use



- ▶ The condensate pipe must be nominally 21.5mm Ø Polypropylene pipe.
- ▶ The condensate pipe work must fall at least 52mm per metre towards the outlet and should take the shortest practicable route.
- ▶ Ensure there are no blockages in the pipe run.

Externally run condensate drainage pipe should terminate at a suitable foul water discharge point, or purpose-designed soak away. If this method is chosen then the following measures should be adopted:

- ▶ The external run be kept as short as possible and not exceed three metres.
- ▶ The pipe diameter should be increased to 32mm and should be insulated using suitable waterproof and weather resistant insulation.
- ▶ The external pipe should take the shortest and least exposed route to the discharge point, and should "fall" as steeply as possible away from the boiler, with no horizontal runs in which condensate might stand.
- ▶ The use of fittings, elbows etc. should be kept to a minimum and any internal "burrs" on cut pipe work should be removed so that the internal pipe section is as smooth as possible.

**4.4.1 Condensate disposal connections**

Condensate drainage pipe can be run above or below ground.

**Key to condensate illustrations**

|    |  |
|----|--|
| 1  | Condensate discharge from boiler                             |
| 2  | Universal connector  |
| 3  | Soil and vent stack  |
| 4  | Minimum 450mm and up to three storeys                        |
| 5  | Pipe work transition   |
| 6  | Insulate and increase pipe size                              |
| 7  | External rain water pipe into foul water                     |
| 8  | External air break   |
| 9  | 43mm pipe (min 100mm upstand)                                |
| 10 | PVCu strap on fitting  |
| 11 | 43mm 90° male/female bend                                    |
| *  | Condensate trap of 75mm already incorporated into the boiler |




Fig. 11 Disposal to a soil vent stack

**Fitting an external air break**

- Refer to figure 12 when a rain water down pipe is used to dispose of condensate.
- An air break must be installed in the 43mm pipe work, between the boiler condensate outlet and the drainpipe, outside the property, to avoid flooding during adverse weather conditions.




Fig. 12 Disposal into a rainwater down pipe

Where the pipe terminates over an open drain or gully, the pipe should terminate below the grating level, but above water level, in order to minimise “wind chill” at the open end.

The use of a drain cover (such as those used to prevent blockage by leaves) may offer further protection from wind chill.

Pipe drainage will be improved if the end is cut at 45° as opposed to a straight cut.




Fig. 13 External drain

**4.4.2 Soak away**



Condensate waste

- ▶ Care should be taken when siting a soak-away to avoid obstructing existing services.

- The condensate drainage pipe may be run above or below the ground to the soak away. The examples shown on this page run above ground.

- The soak away must use a 100mm Ø plastic tube with two rows of three 12mm holes on 25mm centres and 50mm from the bottom of the tube. The holes must face away from the house.
- The tube must be surrounded by at least 100mm of limestone chippings to a depth of 400mm.



Minimum hole size for the condensate soak away must be 400mm deep by 300mm Ø.

In situations where there are likely to be extremes of temperature or exposure, the use of a proprietary trace-heating system for external pipe work, incorporating an external frost thermostat, should be considered. If such a system is used, the requirement to use 32mm pipe does not apply. However, all other guidance above and the instructions for the trace heating system, should be closely followed.




Fig. 14 Disposal to a soakaway

**Key to condensate soakaway**

|    |  |
|----|--|
| 1  | Condensate discharge from boiler                             |
| 2  | Push fit connector   |
| 5  | Pipe work transition   |
| 6  | Insulate and increase pipe size                              |
| 12 | 100mm Ø minimum plastic pipe                                 |
| 13 | Drainage holes   |
| 14 | Limestone chippings (25kg min.)                              |
| 15 | Bottom of sealed tube  |
| *  | Condensate trap of 75mm already incorporated into the boiler |

### 4.5 Pressure relief pipework

- The pressure relief discharge pipe [2] should be at least 15mm diameter copper pipe and run downwards away from the boiler and discharge away from any electrical or other hazard, preferably to an external drain or soakaway.
- Pipe [2] should be finished with a partial bend, near the outlet to prevent discharge onto entrances or other public access where it could cause a hazard.




Fig. 15 Pressure relief pipe work

- [1] External casing
- [2] PRV discharge pipe
- [3] Hardstanding

### 4.6 Boiler locations and clearances

**WARNING:** This appliance should not be installed where there is a potential for excessive ground water coverage. This boiler is only suitable for installing externally at a suitable location onto a fixed permanent, non-combustible, rigid surface capable of supporting the boiler weight. There must be a sufficient hard standing around the appliance to allow for servicing. The boiler must be installed on a flat level surface to ensure that condensate does not enter the primary heat exchanger. Tarmac and wood hard-standings are not recommended.

Clearances:

- ▶ Minimum service and flue clearances.
  - Above - 600mm
  - Front - 600mm
  - RH clearance flue outlet on rear - 300mm
  - LH clearance flue outlet on rear - 10mm
  - Rear clearance flue outlet on side - 50mm
  - Rear clearance flue outlet on rear 2500mm

It is strongly recommended that the flue terminal faces away from walls to reduce the possibility of wetting occurring.




Fig. 16 Above clearance




Fig. 17 Rear exit flue clearances




Fig. 18 Left exit flue clearances





Fig. 19 Right exit flue clearances

## 4.7 Flue gas system considerations



**CAUTION:** Non accessible flue systems:

- ▶ Where a flue system is not going to be accessible, provision must be made for service and inspection.
- ▶ Flue gas system must comply with local standards and regulations.

### Room air dependant operation


The boiler primarily operates as a “room air sealed” unit, however the boiler can be operated as a “room air dependant” unit, if required.

Provide sufficient boiler room ventilation when operating the appliance room air dependent.

- ▶ Do not obstruct or block any ventilation openings.
- ▶ Ventilation openings must always be kept clear.

#### 4.7.1 Combustion air quality


To avoid corrosion, combustion air must be free from aggressive substances (e.g. hydrogen halide, chlorines and fluorine).



**NOTICE:** Damage to appliance from contaminated combustion air and contaminated air in the vicinity of the appliance!

- ▶ Never operate the boiler in a dusty chemically aggressive environment i.e. spray painting, hair dressing and farming facilities.
- ▶ Never operate the boiler in places where using or storing trichlorethane, hydrogen halide and other aggressive chemical substances. These substances can be contained in spray cans, various glues, primers, paints and cleaning substances. In this case, the appliance must be connected in a room sealed configuration.


#### 4.7.2 Flue terminal positions



All measurements are the minimum clearances required

- Flue terminals must be positioned to avoid combustion products entering into buildings.
- The flue must be fitted and terminated in accordance with the recommendations of the latest version of BS 5410:1.
- The flue must not cause an obstruction.
- Discharge from the flue outlet must not cause a nuisance or dispute.
- Flue gases have a tendency to plume and in certain weather conditions a white plume of condensation will be discharged from the flue outlet which could be regarded as a nuisance, for example, near security lighting.
- There should be no restriction preventing the clearance of combustion products from the terminal.
- The air inlet/outlet duct and the terminal of the boiler must not be closer than 25mm to any combustible material. Detailed recommendations on protection of combustible materials are given in the latest version of BS 5410:1.
- Where a vertical flue terminates in an area that is enclosed on 3 sides, the flue must be no more than 1,000mm below the lowest roof line. You must ensure that all clearances are maintained and that products of combustion disperse safely from the area.
- Dimensions from a flue terminal to a fanned air inlet to be determined by the ventilation equipment manufacturer.
- A protective stainless steel terminal guard, must be fitted if the terminal is 2 metres or less, above a surface where people have access.
- See “Contact Information” on the back cover for flue guard information.

- Avoid discharging flue gases into car ports or narrow passageways.



0010023942-002

Fig. 20 Flue terminal positions





**NOTICE:**

- ▶ All measurements are the minimum clearances required.
- ▶ Terminals must be positioned so to avoid combustion products entering the building.
- ▶ Support the flue at approximately one metre intervals and at a change of direction, use suitable brackets and fittings:  
- flue bracket 125mm x 1- Part No.: 7 716 191 179
- ▶ In spite of the dimensions given here, the terminal must not be closer than 300mm to combustible material, in the case of a thatched roof double this dimension.
- ▶ Terminals must be positioned so to avoid products of combustion accumulating in stagnant pockets around the building or entering the building.
- ▶ Terminals must be at least 1.8m from an oil storage tank unless a wall with of at least 30 minutes fire resistance and extending 300mm wider and higher than the tank is between the tank and the terminal.

**Key to illustration 20:**

1. 1,500mm measured between an opening or vented window and vertical flue terminal. This measurement can be reduced to 1000mm providing the flue terminal is at least 300mm above the opening.
2. Minimum clearance to an additional flue, 1,500mm between room sealed flues or room sealed flue and open flue, 1,000mm between open flues.
3. 600mm above a vertical structure less than 750mm from the side of the terminal.
4. The flue must extend at least 600mm above the intersection of the roof (flat and pitched) and be 400mm horizontally from a pitched roof or 500mm in regions with heavy snow fall
5. The flue must not penetrate the roof in the shaded area. The flue must be at least 2,000mm from the opening or vent when sited below the window, 600mm when sited to either side or above. The terminal must be at least 1,500mm room sealed, 1,000mm open flue from the opening or vent when measured horizontally.
6. The flue must not penetrate the roof in the shaded area. The flue must be at least 1,000mm from the opening or vent when sited below the window, 750mm when sited to either side and 300mm above. The terminal must be at least 1,500mm from the opening or vent when measured horizontally.
7. 300mm minimum clearance measured from a non opening skylight to a vertical flue. Vertical flue clearance,
8. 600mm minimum clearance measured from an opening or vented skylight to a vertical flue. If the terminal is within 1,500mm of the opening or vented skylight then it must be at least 600mm above the opening.
9. 750mm clearance to a structure from a vertical flue.  
Not required if the terminal is 600mm above the structure.
10. 750mm adjacent to a boundary line unless it will cause a nuisance. BS 5410: Part 1 recommended that care is taken when siting terminal in relation to boundary lines.
11. 1,200mm separation measured between a vertical flue and a horizontal flue terminal. Not required if the horizontal flue is 1,500mm above vertical flue terminal.
12. 1,000mm (BS 5410-1) above, below and either side of an opening door, air vent or opening window. These clearances are required by BS 5410 Part 1 to reduce a possible plumbing nuisance. If 1,000mm cannot be achieved then the distance can be reduced to 600mm to comply with Approved Document J of the building regulations if it will not cause a nuisance or dispute.
13. 300mm adjacent to a boundary line unless it will cause a nuisance. BS 5410: Part 1 recommended that care is taken when siting terminal in relation to boundary lines.
14. 1,500mm vertically between terminals and the same wall.
15. 1,000mm (BS 5410-1) below eaves, gutters and sanitary pipe and 300mm from vertical sanitary pipes and drains.  
If 1,000mm cannot be achieved then the distance below eaves, gutters and sanitary pipe can be reduced to comply with Approved Document J of the building regulations if it will not cause a nuisance or dispute. 75mm if combustible material is protected or 600mm without protection to combustible material<sup>1)</sup>.
16. The dimension below eaves, gutters, pipes and drains can be reduced to 75mm, as long as the flue terminal is extended by 100mm past any overhang. The telescopic flue joint must be sealed with suitable silicone sealant if it is external to the building
17. 1,200mm between terminals facing each other.
18. 2,500mm (BS 5410-1) distance to a surface or boundary line.  
If 2,500mm cannot be achieved then the distance can be reduced to 600mm to comply with Approved Document J of the building regulations if it will not cause a nuisance or dispute.
19. Terminals must be at least 1,800mm from an oil storage tank unless a wall with of at least 30 minutes fire resistance and extending 300mm wider and higher than the tank is between the tank and the terminal. The flue air intake must be at least 900mm away from the oil storage tank vent.
20. 1000mm diagonally to an opening door, air vent or opening window.
21. 300mm to an internal or external corner. 300mm above a surface, such as the ground/ floor level or roof surface.
22. The dimension below eaves, balconies and car ports can be reduced to 75mm, as long as the flue terminal is extended to clear any overhang. The telescopic flue joint of the terminal must be sealed with suitable silicon sealant if it is external to the building.
23. 1,000mm (BS 5410-1) from an opening or vented window, 300mm to a fixed unvented window. If 1,000mm cannot be achieved then the distance from an opening or vented window can be reduced to 600mm to comply with Approved Document J of the building regulations if it will not cause a nuisance or dispute.
24. The flue terminal must be at least 1,500mm from the opening or vented skylight when sited below the opening or vented skylight.
25. Proximity of flue duct outlet to boundaries, 2000mm distance to an opening in adjacent building facing a terminal. BS 5410: Part 1 recommended that care is taken when siting terminal in relation to boundary lines.
26. The distance between a boundary facing a flue terminal can be measured diagonally from the point of discharge with a minimum distance of 600mm which must be maintained. The exclusion zone ensures compliance with Approved Document J of the building regulations.
27. For the purpose of determining suitable flue terminal positions for oil appliances discharging over public boundaries, the boundary can be considered to extend to the centre line of any adjacent routes or waterways e.g. paths, streets, rights of way, canals, rivers or railways.



**NOTICE:**

- ▶ Installations in car ports are not recommended.
- ▶ Dimensions from a flue terminal to a fanned air inlet to be determined by the ventilation equipment manufacturer.

1) A way of providing protection of combustible material would be to fit a heat shield at least 750mm wide.

## 4.8 Flue options

### 4.8.1 Cabinet mounted balanced horizontal flue options



It is strongly recommended that the flue terminal faces away from walls to minimise the occurrence of wetting.

- The horizontal flue is fitted to the rear or either side of the cabinet.




Fig. 21 Flue options

### 4.8.2 Plume management

- Measure the plume management flue (M) from the centre of terminal, along the required route to the centre of the plume outlet.

| Heatslave II             | Flue length (L) | Plume length (M) |
|--------------------------|-----------------|------------------|
| <b>12/18 &amp; 18/25</b> | 160 - 2000mm    | 500 - 5000mm     |
| Bends                    | maximum of 2    | maximum of 2     |
| <b>25/32</b>             | 160 - 2000mm    | 500 - 4000mm     |
| Bends                    | maximum of 2    | maximum of 2     |

| Effective lengths of elbows |        |        |
|-----------------------------|--------|--------|
| Bend                        | Flue   | Plume  |
| 90°                         | 1000mm | 1000mm |
| 45°                         | 500mm  | 500mm  |

Table 4 Effective lengths of bends

#### Fitting the terminal plume management kit

- Remove and retain the screws that secure the terminal end into the flue.
- Discard the terminal end.
- Fit the terminal elbow into the flue but do not secure with the screws until the plume management system has been assembled.




Fig. 22 Fitting the terminal bend

- Connect the sections of the plume management for desired length.
  - Screw the clamp into the wall.
  - Push the extension/s tube fully into the 90° bend, then withdraw the tube by approximately 10mm to allow for expansion.
- Once the plume management system is in place and secured to the wall, secure the terminal bend with the screws removed earlier.
  - The terminal end can be positioned up to 45° either side of the central position, for plume re-direction.
  - Adjust the plume management terminal end into the desired position and secure with the screws provided.




Fig. 23 Plume management detail

**4.8.3 Plume management considerations**




Fig. 24 Plume terminal positions



**NOTICE:**

- ▶ All measurements are the minimum clearances required.
- ▶ Terminals must be positioned so to avoid combustion products entering the building.
- ▶ Support the flue at approximately one metre intervals and at a change of direction, use suitable brackets and fittings.

**KEY TO ILLUSTRATION**

1. Plume Management kit air intake can be reduced to 150mm providing the flue exhaust outlet is no less than 300mm adjacent to a boundary line.
2. 1,200mm between the terminals on opposing walls. Where two plume management kits are used 1200mm must be maintained between both opposing terminals and air inlets. Each terminal should use a minimum length of 500mm plume management
3. Below balcony or overhang. The air intake clearance can be reduced to 150mm providing the flue exhaust outlet has a 1000mm clearance in BS 5410-1.
4. 300mm distance from a boundary line to the air intake as long as the exhaust terminal faces away from the boundary line. The exhaust terminal must have a minimum 300mm clearance to a surface below and there must be at least 2,500mm (BS 5410- 1) clearance when measured horizontally in a straight line from the exhaust outlet to any other surface. If 2,500mm cannot be achieved then the flue exhaust outlet distance can be reduced to 600mm to comply with Approved Document J of the building regulations if it will not cause a nuisance or dispute.

5. 2,500mm (BS 5410-1) distance to a surface or boundary line. If 2,500mm cannot be achieved then the distance can be reduced to 600mm to comply with Approved Document J of the building regulations if it will not cause a nuisance or dispute.
6. Terminals must be at least 1,800mm from an oil storage tank unless a wall with of at least 30 minutes fire resistance and extending 300mm wider and higher than the tank is between the tank and the terminal. The flue air intake must be at least 900mm away from the oil storage tank vent.
7. 300mm adjacent to a boundary line unless it will cause a nuisance. BS 5410: Part 1 recommended that care is taken when siting terminal in relation to boundary lines.
8. Above, below and either side of an opening door, air vent or opening window. Using a Plume Management kit the air intake measurement can be reduced to 150mm providing the flue exhaust outlet has a 1,000mm (BS 5410-1) clearance. If 1,000mm cannot be achieved then the flue exhaust outlet distance can be reduced to 600mm to comply with Approved Document J of the building regulations if it will not cause a nuisance or dispute.
9. Internal/external corners. The air intake clearance can be reduced to 150mm providing the flue exhaust outlet has a 300mm clearance.
10. Vertical sanitary pipe: 150mm to the flue air intake and 300mm to the flue exhaust outlet.
11. Proximity of flue duct outlet to boundaries, minimum 2,000mm distance to an opening in adjacent building facing a terminal. BS 5410: Part 1 recommended that care is taken when siting terminal in relation to boundary lines.

12. The distance between a boundary facing a terminal can be measured diagonally from the point of discharge with a minimum distance of 600mm which must be maintained. The exclusion zone ensures compliance with Approved Document J of the building regulations,
13. A plume management kit must not be terminated within the confines of a carport or other covered, partially enclosed extension. The exhaust terminal must be sited at least 300 mm beyond the footprint of the structure, and maintain a distance of at least 600mm to any opening sited within the confines of the structure.

The exhaust terminal can also be routed through the roof of the carport providing 25mm clearance is provided around the flue pipe to any flammable material and that it extends at least 300mm above the roof. The air intake must have a minimum 150mm clearance to any opening in the building in order to ensure the integrity of the structure is maintained. If the air intake is sited within the footprint of the carport then the carport must have at least one completely open side.



- ▶ The flue cannot be lower than 1,000mm from the top of a light well due to the build up of combustion products.
  - ▶ Plume kits running horizontally must have at least a 3° fall back to the appliance for proper disposal of condensate. The initial plume kit horizontal run will have at least a 10° fall back to the appliance, due to the terminal elbow design, for proper disposal of the condensate.
-

## 5 Installation

### 5.1 Unpacking the boiler



All the previous Pre-Installation sections must be read and requirements met before starting boiler or flue installation



#### LIFTING AND CARRYING PRECAUTIONS:

- ▶ Lift only a manageable weight, or ask for help.
- ▶ When lifting or putting things down, bend the knees, and keep the back straight and feet apart.
- ▶ Do not lift and twist at the same time.
- ▶ Lift and carry objects close to the body.
- ▶ Wear protective clothing and gloves to protect from any sharp edges.

#### Unpacking

It is advised that two or more persons are involved in the transfer of the packaged boiler from the van to the point of delivery.

- ▶ Once the packaged boiler has been delivered, the outer carton is removed first. Care should be taken when releasing the straps. If a sharp implement is used make sure the outer carton is not pierced and that the implement is used in such a way so that it may not cause personal injury. All sharp objects must be covered or the blade retracted after use and put away in a safe place.
- ▶ Lift carton up and away from the boiler.
- ▶ Remove the plastic bag from the boiler and place safely aside.




Fig. 25

### 5.2 Pipework and flue positions



**CAUTION:** Ensure there are no pipes, electric cables, damp proof courses or other hazards before drilling.



For servicing purposes, keep the condensate and pressure relief (PRV) discharge pipes away from components and pipe work connections.

#### Safety

All relevant safety precautions must be undertaken. Protective clothing, footwear, gloves and safety goggles must be worn as appropriate.




Fig. 26

#### Pipework connections:

- ▶ Flow;
  - 22mm Ø copper 12/18, 18/25 models
  - 28mm Ø copper on 25/32 model
- ▶ Return;
  - 22mm Ø copper 12/18, 18/25 models
  - 28mm Ø copper on 25/32 model
- ▶ DCW In 15mm Ø copper.
- ▶ DHW Out 22mm Ø copper.
- ▶ PRV 15mm Ø copper.
- ▶ Services duct 100mm Ø.
- ▶ Condensate outlet 21.5mm Ø.
- ▶ Primary drain - hose connection.

### 5.3 Boiler installation

**WARNING:** This appliance is serviced & repaired externally.  
▶ 230 V external equipment should not be installed, serviced or repaired in adverse weather conditions.

**i** This appliance is installed and serviced externally to the property, but the engineer must have access to the inside of the property when installing or servicing the appliance.




Fig. 27

**i** The cabinet is not load bearing it only provides weather protection for the boiler inside.

1. Mark position of the 100mm services duct on the exterior wall and make a hole through.
2. Remove the screws securing the base panel to the transit pallet and lift the boiler off the pallet and into its installation position taking care not to scrape the base panel across the hard standing.  
**Do not attempt to lift and position the boiler on your own. Do not use the copper pipes to move the boiler.**
  - Fasten the base to the hard standing using the holes provided. Care should be taken to ensure that the base is level.
3. Remove the screws [D] from each corner of the top panel [E] and lift up to remove.  
To release the back panel, remove the two screws from the bottom corners and lift the panel and pull towards to remove. Store the panels safely away from the installation point.
4. Remove the key [A] for the door fasteners from the literature pack. Using the key, turn the latches at the bottom of the front panel [B] through 90° to release the panel. Lift the panel and pull towards you to remove. Store the panel safely away from the installation point.
5. Pull control box drawer [G] forward.

- Depress the two levers [H], one on either side beneath the slide rail, to release the control box and pull fully forward.
  - Swivel the complete control box assembly upwards.
6. Swivel the expansion vessel [J] and support bracket out of the boiler, taking care not to snag any electrical cables or kink the flexible hose.
  7. Unplug the burner lead [K] from the control box lead [L].
  8. Loosen the flexible air duct clamp [M] and remove the air duct from the burner.
  9. Undo and remove the retainer [O] on top of the burner. The burner [P] can now be removed from the heat exchanger. Store the burner and retainer nut safely away from the boiler.
    - Measure the 100mm Ø services duct to give at least 10mm inside the casing and to finish flush with the interior wall surface, cut to size and fit the duct. Fit the 100mm sealing ring where the duct enters the casing and seal the joint to the exterior wall and inside the cabinet with a suitable sealant.

### 5.4 Flue installation

#### 5.4.1 Flue Components




Fig. 28 Flue components

- [1] Air inlet clamp
- [2] Telescopic air inlet section & acoustic insulation
- [3] 80mm Ø flue pipe (including seal)
- [4] Air box mounting bracket
- [5] Air box gasket
- [6] Air box
- [7] Air box cover
- [8] Flue terminal
- [9] Air box cover screws x 6
- [10] Mounting screws x 4 (Accessory pack)

#### 5.4.2 Rear Flue options \_ Greenstar - all models

**NOTICE:**  
▶ Ensure inner flue is cut to the correct length as specified in Table 5 before fitting.

| 80mmØ flue pipe length L in mm |                   |
|--------------------------------|-------------------|
| Flue outlet                    | Greenstar Boilers |
|                                | Heatslave II      |
| Rear                           | 465               |

Table 5 Flue pipe lengths

- ▶ Fit the air inlet telescopic sections [2 & 3] to the boiler flue cowl and secure the inner section with the clamp [1].
- ▶ Push the air inlet outer section [3] (see figure 31) through the rear panel opening until the end of the tube is against the stops [4] on the clamp assembly [5].




Fig. 29 Rear flue

- [1] Flue clamp
- [2] Telescopic inner section
- [3] Telescopic outer section
- [4] Clamp stops
- [5] Clamp assembly

- ▶ Drill through the two sections of the flue inlet [2 & 3] with the 3.3mm drill bit and secure the two sections with the self-tapping screw.
- ▶ Drill through the tab [6] with the 3.3mm drill bit, into the flue inlet outer section [3] and secure with the self-tapping screw.




Fig. 30 Drilling detail

- [2] Telescopic inner section
- [3] Telescopic outer section
- [6] Clamp tab

#### 5.4.3 Side Flue options - Heatslave II




To use the right hand or left hand flue options a 90° swept flue elbow is required (part no. 7 716 190 034) Lightly grease the 90° flue elbow seals with the solvent free grease.

#### Flue options - Greenstar Heatslave II

| 80mmØ flue pipe length L in mm |              |
|--------------------------------|--------------|
| Flue outlet                    | Heatslave II |
| Right hand                     | 230*         |
| Left hand                      | 340**        |

Table 6 Flue pipe lengths

- [\*] Heatslave II right-hand flue:  
the 125mm air inlet outer section is not needed for these outlet position and so there will be one screw spare.
- [\*\*] Heatslave II left-hand flue:  
Use both inner and outer air inlet sections, but cut the outer section down to 150mm.
- ▶ Cut the 80mm flue pipe as required, see table 6
- ▶ Fit the air inlet section [2] to the elbow [3].
- ▶ Fit the clamp [1] to the flue cowl.




6720807912-11.1Wo

Fig. 31

- [1] Flue clamp
- [2a & 2b] Flue section

- ▶ Push the air inlet section through the side panel opening into the air box until it meets the stops [4] on the clamp assembly
- ▶ Centralise the inner elbow pipe within the elbow.
- ▶ Fit the elbow [3] onto the flue cowl.
- ▶ Tighten the clamp [1] onto the flue elbow.




6720807912-12.1Wo

Fig. 32

- [3] Elbow
- [4] Clamp stops
- [5] Clamp

- ▶ Drill through the tab [6] on the mounting bracket, with the 3.3mm drill bit into the air inlet outer section and secure with a self-tapping screw.




6720807912-13.1Wo

Fig. 33 Tab detail

#### 5.4.4 All flue options, final assembly

- ▶ Lightly grease the flue pipe seal with the solvent free grease supplied.
- ▶ Remove the screw from the clamp bracket [1] and open the clamp.
- ▶ Insert the terminal [3] fully into the 80mmØ flue pipe.
- ▶ Pass the flue pipe [2] through the clamp bracket [1] and push into the flue cowl or elbow.



6720807912-17.1Wo

Fig. 34 Final assembly

- [1] Clamp bracket
- [2] Flue pipe
- [3] Terminal

- ▶ Drill two holes into the terminal [3] through the tabs [5], with the 3.3mm drill bit, one either side, and secure the terminal [3] to the tabs [5] using the two self tapping screws.
- ▶ Fit the air box cover [4] over the lip on the top of the air box and secure the bottom two screws removed earlier.






Fig. 35

- [4] Air box cover
- [5] Tab

**5.4.5 Terminal guard**

- ▶ To fit the terminal guard [1] not supplied:  
Hold the terminal guard [1] in place and secure with the four screws [2] removed from the air box earlier.




Fig. 36

- [1] Terminal guard
- [2] Screws

**5.4.6 Flue damper installation**



**NOTICE:** Fitting the flue damper  
Failure to fit the flue damper, when required will effect the performance of the boiler and may cause Lockouts



The flue damper is only fitted to models stated in the table below

| Model range  | Output (kW) | Flue damper fitted   |
|--------------|-------------|----------------------|
| <b>12/18</b> | 13          | Yes                  |
|              | 15          | Yes                  |
|              | 18          | Yes                  |
| <b>18/25</b> | 18          | Yes                  |
|              | 21,5        | Yes                  |
|              | 25          | Yes                  |
| <b>25/32</b> | 25          | No                   |
|              | 28          | No                   |
|              | 32          | Yes ≤ 4m flue length |
|              | 32          | No > 4m flue length  |

Insert the flue damper into the inner tube of the straight extension or 90° elbow and fit the flue as shown in figure 37. Ensure that the rubber seal is fitted into the inner tube.




Fig. 37 Flue damper fitting

**5.4.7 Installation notes**

- ▶ Ensure all the seals are in good condition and seated properly.
- ▶ To ease assembly of flue components, grease seals lightly with the solvent free grease supplied.
- ▶ A terminal guard must be fitted if the terminal is 2metres or less above a surface that can be accessed by people.

**5.4.8 All flue options**

- ▶ Lightly grease the flue cowl seal with the solvent free grease supplied.
- ▶ Carefully remove the blanking plate from the appropriate flue aperture (if necessary) and refit the blanking plate in the unused aperture.
- ▶ Carefully remove the insulation from the flue aperture in the cabinet that the flue is to pass through, and fit to the unused aperture.

**5.5 Combustion chamber**

- ▶ Unscrew screws [G] and remove flue manifold access cover [H].
- ▶ Check that all the baffles [J] and baffle retainer [K] are correctly fitted to the secondary heat exchanger.
- ▶ Check that the flue damper, if required, is fitted correctly, refer to section 5.4.6
- ▶ Remove the retaining nuts and washers [B].
- ▶ Remove combustion chamber/baffle access door [A].




Fig. 38

- ▶ Ensure one piece baffle set [C] is in the right location [D], correctly resting on the baffle rests [F] on either side of the combustion chamber and pushed securely into place. Baffle sets for the 18/25 and 25/32 boilers are identified with tabs on the front and rear edge




Fig. 39

- ▶ Refit combustion chamber door [A].

**i** Secure with nuts and washers [B] and tighten until the chamber door is firmly secured, do not over tighten the nuts.

## 5.6 Pipework connections

**CAUTION:** Isolate the oil & water mains supply before starting any work and observe all relevant safety precautions.

### Water connections

- ▶ Ensure all pipework is clean.

**i** That surplus water may be present due to factory testing.

- ▶ Align water pipework and connect
- ▶ Check that all unused sockets have been capped.

### Oil supply connections

- ▶ Route the oil supply pipe [W] along either side of the boiler as required and connect to the isolating valve [G] and ensure the valve is closed.

**i** Replace flexible hose at annual service to prevent possible oil leakage.

- ▶ Connect the flexible oil hose [H] to the isolating valve [G].

### Condensate connection

Refer to figure 40 on page 27

- ▶ Connect 21.5mm polypropylene pipe [L] (not supplied) to the condensate waste pipe flexible push fit connector [K] and terminate to waste.
- ▶ Do not use any solvents, adhesives or lubricants when pushing the pipe into the rubber connector [K].
- ▶ Ensure that the condensate pipe runs away from the boiler at a constant fall of 52mm (min.) for every metre.
- ▶ Seal all condensate pipe joints.
- ▶ Carefully pour 500ml of water into the condensate collection [U] to fill condensate trap.
- ▶ Check the water is running away and the condensate pipework joints are water tight.
- ▶ Check the flue manifold seal (within the rim recess of the flue manifold access cover) is undamaged and seated correctly.
- ▶ Refit flue manifold access cover [T] and secure with screws [S].

**i** The condensate trap must be correctly filled to prevent the possibility of potentially harmful flue products escaping via the condensate pipework.

### Pressure relief connection

- ▶ Connect the pressure relief pipe [N] to a copper discharge pipe (15mm Ø min.).




Fig. 40 Pipe connections

- [A] CH flow 22mm Ø copper (28mm Ø on 25/32 models)
- [B] DHW flow 22mm Ø
- [C] DHW water main inlet 15mm Ø
- [D] CH return 22mm Ø copper (28mm Ø on 25/32 models)
- [F] 10mm Ø oil supply connection
- [G] Oil isolating valve (10mm Ø)
- [H] Flexible oil hose (Replace hose at annual service to prevent leaks)
- [J] Flue manifold condensate outlet
- [K] Condensate outlet and flexible push fit connect (21.5 mm Ø) - supplied
- [L] Condensate pipe - not supplied
- [M] Condensate trap - supplied
- [N] Pressure relief (15mm Ø)
- [O] Drain
- [P] Fixing point for optional return oil pipe
- [S] Manifold access cover screws
- [T] Flue manifold access cover
- [U] Condensate collection sump
- [W] Oil supply pipe (not supplied)

**Fire valve**

Check that the oil supply pipe has a fire valve fitted externally to the building and appliance with the fire valve sensor located in the case. A fire valve sensor clip [1] is provided for this purpose on the support bar between the side panels.




Fig. 41 Fire valve clip

- [1] Fire valve clip
- [2] Fire valve label

The fire valve label [2] states that the fire valve should be rated at 85°C or above to avoid nuisance cut outs.

**5.7 Oil burner and pump**

**CAUTION: MAINS SUPPLIES**

- ▶ Isolate the oil & water mains supply before starting any work and observe all relevant safety precautions.

**NOTICE: Nozzle orifice contamination**

- ▶ to avoid contamination do not dismantle, clean or touch the nozzle tip

**Oil burner nozzle**

Before removing or fitting a new nozzle refer to figure 42:

- ▶ Remove the screws [1] from the blast tube [2] and remove the blast tube

**i** There is a recirculation tube fitted to the 12/18 models, this does not need to be removed from the blast tube

- ▶ Unplug the HT leads [4]
- ▶ Loosen the screw [3] securing the break plate[5] and slide the unit off
- ▶ Use a suitable spanner to stop the nozzle body turning
- ▶ Remove the nozzle [8]and secure the new nozzle, hand tight
- ▶ Tighten the nozzle utilising the two spanners used during removal, do not overtighten
- ▶ Refit the break plate ensuring that the photocell and the break plate hole [5] are aligned and secure with the screw [3] into the seating provided [7]
- ▶ Reconnect the HT leads [4]
- ▶ Refit the blast tube [2] and secure with the screws [1]




Fig. 42 Nozzle access

Refer to figure 43:

- ▶ Check that the nozzle [1] and the electrode [2] alignment settings are correct.
- ▶ Ensure that the nozzle [1] is aligned centrally within the combustion head [3].
- ▶ Inspect for any visible defects.




Fig. 43 Nozzle and electrode alignment

**Burner head adjustment**

The burner head adjustments are made to achieve the required output from the burner. The adjustments are made via a thumb-wheel on the burner. Refer to section 6.3.3 for setting information.

**Oil pump - Single pipe connection**

Connecting the oil pump for a single pipe system:

- ▶ The pump is factory set for single pipe operation with the flexible oil pipe fitted.
- ▶ Check connections before use.

**Oil pump - two pipe connection**

Converting the oil pump for a double pipe system:

1. Check the inlet pipe connection.
  - ▶ Unscrew the return plug [1].
  - ▶ Screw in by-pass screw [2] that is supplied in a plastic bag attached to the oil pump.
2. Connect the flexible oil pipe return hose [3] (not supplied) to the oil pump and return pipe fixing and tighten to secure (for routing see figure 40.




Fig. 44 Converting to double pipe system

- [1] Return plug
- [2] By-pass screw
- [3] Return pipe connection

**5.8 Refitting components**

**WARNING:** Flue gas leakage.  
The seal between the burner and the mounting flange must form a gas tight seal to prevent leakage of potentially dangerous gases from the combustion chamber.

- ▶ Unless the burner is level when pushing the burner into the flange the O ring may not seat properly allowing flue gas to escape!
- ▶ Always check that the O-ring seal (Fig. 45 item A) is in good condition before fitting the burner. Replace the O-ring seal if defective.




Fig. 45 12/18 Burner O-ring seal shown

Refer to figure 46

1. Align burner combustion head into the boiler collar.
  - ▶ Locate the burner retainer [A] over the threaded lug on the collar [B], ensure that the burner is level and push the burner firmly onto the flange ensuring the O-ring seal is fully engaged. Support the burner in position and secure with the retaining nut [C]. Tighten sufficiently to hold the burner but do not over tighten.
  - ▶ Check that the burner is seated correctly on its mounting flange and that the oil hose/s are routed correctly as shown in Fig. 40 on page 27 and not trapped in front of or underneath the burner.
2. Refit the flexible air duct and secure with clip [D].

3. Plug burner lead [G] into connector [H].
4. Swivel the expansion vessel [H] back into position taking care not to kink the flexible hose or snag electric cables.
5. Refit control box.
  - ▶ Rotate the box towards you [J].
  - ▶ Slide control box drawer back into position.
6. Refit the top panel [K] and press down to compress the seal when fitting the securing screws.
7. Push the front panel [L] up behind the top panel and push in at the base, using the key [N] secure the panel with the latches [M]. Always apply pressure at the edges of the boiler panels when securing to avoid accidental damage.




Fig. 46

6 720 805 210-16.2W0

## 5.9 Electrical



**CAUTION: ISOLATE THE 230V ELECTRICITY SUPPLY**

- ▶ Ensure that the electricity supply is safely isolated and secured to prevent inadvertent re-connection. Information on safe isolation can be found in the Health and Safety Executive guidance HSG85. Using test equipment approved to GS38 confirm that the electricity supply is disconnected



**NOTICE:** This appliance provides a permanent external electrical supply for servicing and frost protection and must therefore be fed via a circuit breaker incorporating earth leakage protection.



**NOTICE:** Follow electro-static discharge precautions. do not touch the PCB circuits or components.



**WARNING:** External equipment operated at 230 volts should not be serviced or repaired under adverse weather conditions.



The mains electrical supply to the boiler and system wiring centre must be common and through a common fused double pole isolator. The isolator must have a contact separation of 3mm minimum between the poles. Any additional components that are connected to the boiler with mains electrical supply must not have a separate supply. External fuse 5 Amps. When stripping wires ensure copper strands do not fall into the control box.



**NOTICE:** When wiring mains and control cables ensure that the cable has sufficient length for the control box to be slid forward and tilted over.

### Access to electrical connections

Access to all wiring connections are via the Installer access cover at the bottom front of the control board.

1. Release the 3 captive screws [C] and remove the Installer access cover [D].

### Electrical connections

2. E. Low voltage connections.  
G. Mains voltage connections.  
H. Fuse carrier.



**DHW LR switched live:** This input provides the live feed in from a connection for a proprietary twin channel control to time the tank reheat function on the DHW. All Worcester twin channel digital controls provide this functionality, but the link is required for them to function.




Fig. 47

**DANGER: 230 Volts**  
Isolate the mains electricity supply before starting any work and observe all relevant safety precautions.

**Frost protection**

The boiler has built in frost protection to protect the appliance and the system within the heated building.




Fig. 48 External 230 V Twin Channel Programmer and Room Thermostat




Fig. 49 Optional External 230 V AC Frost Stat Connection for protection of system pipework in unheated air space

- ▶ Connect frost thermostat cables to terminals FS & FR.
  - These connections are not polarity sensitive.
  - The Boiler internal frost protection will bring on the burner if required.

5.10 Electrical schematic




Fig. 50

- |                                      |   |
|--------------------------------------|---|
| [1] Fuse (slow blow) 5A              | [14] Diverter valve                                   |
| [2] Worcester 24V controls point     | [15] Tank overheat thermostat                         |
| [3] Storage tank temperature control | [16] Circulation pump                                 |
| [4] EMS bus connections              | [17] Tank sensor                                      |
| [5] Diagnostic port                  | [18] Flow turbine                                     |
| [6] Flow sensor                      | [19] Boiler earth                                     |
| [7] Max safety sensor                | [20] DHW outlet sensor                                |
| [8] Burner plug                      | [21] DCW inlet sensor                                 |
| [9] Burner socket                    | [22] LCD display                                      |
| [10] Shut off valve connector        | [23] HCM) Heat control module)                        |
| [11] Flue overheat thermostat        | [24] Central heating temperature control              |
| [12] Air pressure switch             | [25] Burner service mode switch                       |
| [13] Burner control                  | [26] Pre-wired links                                  |
|                                      | [BK] Black [RD] Red [OG] Orange [WH] White [GN] green |

### 5.11 Weather compensation

The appliance will modulate the CH flow temperature based on the outside temperature when an outdoor sensor is connected to the outdoor sensor connection on the control board and the weather compensation is active.

This is designed for use with a system that has thermostatic radiator valves and a room thermostat.

The appliance will operate at lower temperatures when there is a lower heat load because the building is losing less heat due to higher external temperatures. This means that the appliance is running more efficiently as it is operating for longer at condensing temperatures.

The weather compensation curve can be adjusted to tune the flow temperature to suit the particular installation.

The appliance is supplied with the weather compensation deactivated.

#### Weather compensation activation

The weather compensation is activated via menu 1 of the text display.

- ▶ Select Menu 1 via ▲ ▼ scroll buttons.
- ▶ Press OK button.
- ▶ Select W1 via ▲ ▼ scroll buttons.
- ▶ Press OK button.
- ▶ Set W1 to 1 via ▲ scroll button.
- ▶ Press OK button.

The weather compensation is now active and the appliance will check for the presence of an outdoor sensor and deactivate the CH flow temperature modulation if a sensor is not detected. When weather compensation is activated but an outdoor sensor is not fitted/detected, the warning triangle and H03 will be displayed on the LCD display.




Fig. 51

Weather compensation sensor optimum siting indicated by black tick.




Fig. 52


The sensor is wired directly into the control box via terminal 4 in the low voltage terminal strip (→ page 30).

#### The heating curve

The CH flow temperature has an upper limit of 82°C (this can be capped via the CH control knob setting) and a lower limit of 50°C, (it is recommended that the CH knob is set to 82°C for the weather compensation to operate most effectively).

The default settings for the curve are point A = 90°C and point B = 40°C, this gives a 80°C flow at -4°C outdoor temperature and a 50°C flow at 14°C outdoor temperature which should be suitable for typical systems.

Point A is the projected value for the flow temperature at -10°C outdoor temperature and point B is the projected value for the flow temperature at +20°C outdoor temperature, (these values dictate the angle of the slope only they are not CH flow temperature limits).



#### Adjusting the heating curve

- ▶ The weather compensation curve can be adjusted via the text display by adjusting the projected flow temperature at -10°C (point A), Menu 1 W2 (pA), and 20°C (point B), W3 (pB), enabling the slope as well as the position of the curve to be adjusted to suit the installation.
- ▶ Point A and B can be set between 90 and 20°C but point A must always be greater than point B.

#### Outdoor sensor error

- ▶ If during weather compensation the outdoor sensor is open circuit or closed circuit the CH flow temperature modulation is deactivated and the CH flow temperature set to the CH control knob setting, a warning triangle and H03 are displayed on the LCD.
- ▶ The appliance will monitor the outdoor sensor input and if the sensor returns to normal then the flow temperature modulation will be reactivated and the LCD warning triangle and H03 are turned Off, (there may be a 10 second delay).

#### Average outdoor temperature

- ▶ To stop rapid fluctuations the outdoor temperature used for CH flow temperature modulation is an average value taken over a ten minute period.
- ▶ When an outdoor sensor is first detected the sensor value is taken to be the outdoor temperature, subsequent to this the outdoor temperature will be adjusted every 10 minutes using an average outdoor temperature value from the previous 10 minute period.

#### Frost protection

The normal condition for the appliance is that the weather compensation frost protection is turned Off.

If required the frost protection is activated via Menu 1 W5 of the text display, 0 = OFF, 1 = ON.

On Activation of the weather compensation frost protection if the outdoor temperature is less than 5°C the system frost protection is activated the same as if an external frost thermostat was activated.



## 6 Commissioning

### 6.1 Pre-commissioning checks-appliance

**CAUTION:** Isolate the mains supplies before starting any work and observe relevant safety precautions.

1. Check that the service and water pipes are connected correctly.
  2. Check that the oil supply is Kerosene (Class C2) and that the pipework is connected correctly to the oil pump via the supplied flexible oil hose (→ correct routing for flexible hose on page 27).
- Turn on the main oil supply valve at the tank, check the oil supply pipework and connections. Rectify any leaks.

**i** Replace flexible hose at annual service to prevent possible oil leakage.

3. Check the flue is correctly fitted and the connections are secure.
  4. Check the condensate pipework is correctly fitted and connected.
- Check the condensate trap is filled with water.




Fig. 53

**NOTICE:** If the boiler is not to be commissioned immediately then: After successfully completing all of the checks and any rectification work, close the water valves, shut off the oil supply and electrically isolate the boiler. Complete the installation part of the Guarantee Registration Card, and complete a CD10 or equivalent to inform the LABC of the installation.

### 6.2 Filling the system

1. The diverter valve will sit in mid-position when the boiler has no demand and is powered up.




Fig. 54

2. Loosen the flow pipe manual air vent screw.




Fig. 55

3. Check and if required, adjust the expansion vessel pressure using the Schraeder type valve [A].




Fig. 56

The charge pressure of the built-in 12 litre expansion vessel is 0.7 bar as dispatched, which is equivalent to a static head of five metres. At 1 bar pressure the vessel will provide 107 litres expansion capacity, the boiler has a primary water capacity of between 62 and 64 litres and therefore additional system expansion capacity may be required.

| Total system volume (litres) | Initial system pressure (bar) | Initial charge pressure (bar) |
|------------------------------|-------------------------------|-------------------------------|
| 180                          | 0.5                           | 0.5                           |
| 107                          | 1.0                           | 0.5                           |
| 138                          | 1.0                           | 1.0                           |

Table 7

If an extra expansion vessel is fitted to the central heating return, adjust this to the same pressure as the appliance internal expansion vessel, refer to separate instructions supplied with the extra expansion vessel.

4. Open all system and radiator valves.
  - ▶ Turn on the water main stop cock.
  - ▶ Close the flow pipe manual air vent when water is vented.
  - ▶ Fill the system to between 1 and 2 bar pressure via a WRAS approved filling link. Monitor the pressure gauge during venting and repressurise if required.
  - ▶ Check air is being discharged from the automatic air vents.
  - ▶ Vent all radiators, retighten when completed, check the system and correct any leaks.
  - ▶ Bleed air from both of the secondary heat exchanger air vents [B] and flow pipe air vent.
  - ▶ Bleed air from the pump using the pump bleed screw.




Fig. 57

5. Connect a suitable hose to the Heatslave tank drain. Open the drain valve to reduce the system to the correct pressure, then close the drain valve. Ensure safe disposal of the discharge.




Fig. 58

6. Check system and rectify any leaks.

### 6.3 Starting the appliance

**NOTICE:**  
Never run the appliance when the appliance/system is unpressurised or empty.

1. Check the oil supply is correctly fitted, pressure tested and in good working order before turning on the oil supply valves to the boiler.

- ▶ Turn on the main oil supply valve at the tank and draw off at least 2.5 litres of oil until a steady flow of clear uncontaminated oil can be seen as follows:
  - The oil supply to the boiler should be primed before the burner is operated to avoid unnecessary pump wear.
  - The use of an oil suction pump will prime and flush through any oil supply set up simply and easily, alternatively the following procedures can be used.

#### 6.3.1 Single pipe gravity feed systems:

- ▶ Disconnect the flexible oil hose and open the isolating valve to discharge the oil into a suitable container.
- ▶ If a top entry tank has been used the pipework will need to be primed before the oil will discharge under gravity.
- ▶ When completed, close the isolating valve, reconnect the flexible oil hose.

#### When the oil reaches the pump, bleed the air from the pump:

- ▶ Open the isolating valve and the oil pump bleed port [1] to discharge into a suitable container once the boiler is started up.
- ▶ Switch on the electricity supply to the boiler.
- ▶ Set the programmer to ON for CH and DHW.
- ▶ Turn on the boiler CH control thermostat.
- ▶ Allow the burner to run through to lockout indicated by the control panel LCD display [J] showing code 9F 855.




Fig. 59

- [1] Bleed and pressure gauge port
- [2] Vacuum gauge connection
- [3] Pressure adjuster
- [4] Cover retaining screws x4

#### If no oil comes out of the port valve [1], then re-prime the oil line as detailed above

- ▶ Wait 2 minutes then press the lockout reset button .
- ▶ Repeat the procedure until a steady stream of oil without air, runs from the bleed port, then lock bleed port [1].
- ▶ Switch off the boiler.

#### 6.3.2 Double pipe sub-gravity feed systems and single pipe suction lift with de-aerator:

- ▶ Prime the oil supply pipework to prevent oil pump damage.
- ▶ To prime a de-aerator [2], disconnect the flexible oil inlet hose [7] from the isolation valve and place in a container of heating oil[6]. Connect a spare flexible oil hose [5], to discharge into container [6]. Open the isolating valve, turn on the power to the boiler and set the programmer to ON. Prime the de-aerator until there is a steady flow of oil into container [6]. Turn off the boiler then reconnect the flexible oil inlet hose [7].
- ▶ Turn on the boiler, the oil level in the de-aerator will drop whilst the oil is being drawn from the tank. If the de-aerator empties and the burner locks out before the oil is drawn from the tank, you will have to prime the de-aerator again.




Fig. 60 Priming the pump

- [1] Oil supply
- [2] De-aerator
- [3] Return
- [4] Flow
- [5] Spare flexible oil hose
- [6] Container of oil
- [7] Oil pump flexible inlet hose
- [8] Bleed and pressure gauge port

2. Fit a suitable pressure gauge to port [8] on the oil pump.

**NOTICE:**

If changing the burner output, ensure the position of the air damper disk is correct for the desired output. Refer to table 9.

► **12/18 & 18/25 - RIELLO RDB 2.2**

Adjust position of the air damper disc to suit the burner output (→ table 9 on page 39), located as shown in figure 61. Access is by removing the two screws (SC) to release the air inlet manifold [1].

► **25/32 - RIELLO RDB 2.2**

No damper disk is fitted to the 25/32kW burner.




Fig. 61

**6.3.3 Burner head setting**

Adjustments to the burner head are made on the basis of the required output, refer to table 9 for the required setting for your boiler.




Fig. 62 Burner head adjustment thumbwheel

One complete rotation clockwise (cw) from the minimum position equals approximately one millimetre. Adjust the thumb-wheel to achieve the setting indicated in the table 9, according to your appliance model and output.

Using an engineer's rule or vernier gauge measure from the lip of the blast tube to the inside of the break plate as show in the figure below. Ensure that the break plate is level, check at four equal points to get an average of the required setting. The setting tolerance should be no more than  $\pm 0.25\text{mm}$




Fig. 63 Burner head adjustment

**6.3.4 Boiler lockout**

If the burner fails to establish a normal firing pattern or flame failure occurs the flame monitoring photocell mounted in the burner body will alert the burner control box to shut the burner down and provide a safe lockout state indicated on the control panel LCD display [J] by code 9F 855.




Fig. 64

- ▶ Wait two minutes then press the lockout reset button [K] to initiate another start sequence.
- ▶ Repeat procedure until a flame is established.
- 1. Start and run for three minutes then switch off.
- ▶ Release the burner retainer nut [H].
- ▶ Remove the burner.
- ▶ Check for after-spurting from the nozzle, indicated by oil saturation on the combustion head [G]. *If after-spurting occurs:*
- ▶ Remove the combustion head [G], and electrodes, hold the burner vertically, unscrew the nozzle and fill the nozzle holder with oil.
- ▶ Refit nozzle, electrodes, combustion head [G] and the burner.
- ▶ Restart and run for three minute intervals until after-spurting stops.




Fig. 65

- 2. Start and run for 20 minutes.
- ▶ Check that the oil pressure is set according to table 9 on page 39
- ▶ Remove sampling point plug [J] to check the smoke reading is between 0-1. If the smoke level is above 1, check the combustion settings are correct and the oil nozzle is in good condition.




Fig. 66

**i** Smoke readings may be inaccurate until the smoke from burning organic binder in the access door insulation has ceased.

### 6.3.5 Switching the appliance on/off

- ▶ Turn on the mains power supply, initially the “Boiler start up screens” will be displayed (see figure 68:)
- ▶ Turn on any external controls.
- ▶ Set the thermostatic radiator controls to maximum.

- ▶ Set the clock/programmer to continuously ON and the room thermostat to maximum temperature




Fig. 67

#### Control board:

- [1] Spanner/return button
- [2] Reset button
- [3] ECO button
- [4] Boiler LCD display
- [5] Central heating temperature control
- [6] Scroll up button
- [7] OK - Select/confirmation button
- [8] Scroll down button
- [9] Operation and fault indicator (blue)
- [10] Position for optional programmer
- [11] Hot water temperature control
- [12] Diagnostic port
- [13] System pressure gauge
- [14] Burner service mode button

**The blue operation/fault indicator light will be illuminated when there is a demand for heat or hot water.**

- ▶ Turn the boiler CH temperature control [5] to maximum.

**If the boiler fails to light, a flashing fault code will be displayed.**

**i** Do not press the blue operation/fault indicator [9] to attempt to reset the boiler.

- ▶ To reset the boiler, press the reset button [2], the “tick” symbol will be displayed briefly for a successful reset.

#### Boiler start up screens

On initial start up, the following screens are displayed:

1. All the symbols are displayed for approximately 2 seconds.
2. The control will run an internal test.
3. When the internal test has been successfully performed, this screen is displayed:
  - ▶ The boiler is in stand-by.
  - ▶ The flow temperature sensor indicates the primary temperature from the heat exchanger (not the target set point).
4. If no adjustments are made for 30 seconds, the back light goes off.
  - ▶ As soon as an adjustment is made, the screen will light up and the relevant information will be displayed.




Fig. 68 Start up screens

**Screen display**

All possible screen symbols are displayed briefly during start up. Extended diagnostic features have rendered the greyed out symbols not required for the operation of this appliance.




Fig. 69

- [1] **Central heating symbol**  
Displays this symbol during CH demand.
- [2] **Hot water symbol**  
Displays this symbol during DHW demand (DHW flow rate > 2 litres per minute) and tank reheat.
- [3] **Weather Compensation active symbol**  
Displays this symbol only if a Weather Compensation sensor has been fitted to the appliance and is active.
- [4] **Alert symbol**  
Displays with the boiler status code and diagnostic code during a fault condition.
- [5] **Service mode symbol**  
Displays when in the service menu.

- [6] **Centigrade symbol**  
Displays next to the temperature reading.
- [7] **Confirmation symbol**  
This symbol confirms a manual change.
- [8] **Alpha/Numerical display**  
Displays a temperature or boiler status code.
- [9] **Text display**  
Displays ECO or diagnostic code.

**Status code**

During normal operation various status codes can be displayed by pressing the service button.

The first screen of the information menu displays the current status code, this will change as the boiler runs through the various modes and sequences.

These are not faults, but provide information concerning the current status.

| Status Code |                            |   |
|-------------|----------------------------|---|
| 200         | CH active                  | The Central Heating system is being heated.   |
| 201         | DHW active                 | The Domestic Hot Water is being heated/tank is being heated.  |
| 202         | CH Anti rapid-cycle mode   | Time delay to prevent rapid-cycling of the boiler on the room thermostat.   |
| 203         | System stand-by            | The boiler has no CH or DHW demands.  |
| 270         | Power up mode              | The boiler is ON, warming up and running self check routines. This lasts approximately 35 seconds.  |
| 358         | Three way valve anti-seize | Anti-seize operation. If the diverter valve has not moved in 24 hours, the valve is operated to prevent seizing, duration approximately 10 seconds. |

Table 8

**6.3.6 Selecting Service Menus**

1. Press and hold and buttons together for 1 second, the display will show Menu 1.

Double up or down arrows indicate that the menu can only be scrolled up or down.

An up and down arrow indicates position in the menu where options can be scrolled either up or down.




Fig. 70

- 1. Scroll up and down through the menus with the arrow buttons




Fig. 71

**Menu 2 - Boiler parameters**

- 3. Select Menu 2 via the and arrow buttons.
- ▶ Press and hold OK button, for 1 second to enter Menu 2. The menu lists the boiler parameters, that can be adjusted in this menu.




Fig. 72

**To modify setting**

- 4. Select the desired menu option using the arrow buttons (refer to figure 73) and press the OK button, the option will flash.
- ▶ Adjust the parameter using the up and down arrow buttons and press the OK button to confirm.

A tick will appear on the display for 3 seconds to confirm the update of the new value.

The same process is used for adjusting Menus 1 & 2.




Fig. 73

**Menu 2 parameter**

|   |   |
|---|---|
| <b>2.7A</b> Demand /fault indicator (blue light) activation | 0 = The blue light will only operate as a flashing fault alert.<br>1 = The blue light will operate as a boiler demand light and fault alert. This is set to 1 by default. |
|---|---|

**Reset to factory settings**

To reset any or all changes made in Menu 2 back to the factory default setting:

Any changes made to Menu 1 are not reset by these actions.

- 1. Press and hold the and buttons for at least five seconds. The screen will then display code 8E and spanner symbol.




Fig. 74

- 2. Press the button and “reset” will be displayed with the tick symbol for three seconds. After three seconds the display will revert to the normal operation screen.




Fig. 75

**6.3.7 Finish commissioning boiler checks**



APPLIANCE MUST BE SET TO CO<sub>2</sub> LEVELS.  
Air settings are approximate, as flue length and nozzle variations will affect them.

Check the CO<sub>2</sub> levels, refer to table 9 and adjust the air shutter [4].

► Check the flue gas temperature is close to the values in table 9.  
*If the flue gas temperature is too high and the baffles are correctly fitted, then reduce the oil pump pressure [2] 5-10 p.s.i. to compensate for nozzle variations.*

- Turn off the electrical supply.
- Isolate the oil supply to the burner.
- Remove the oil pressure gauge.
- Refit the blanking plug [1].
- Check and rectify any oil leaks.

3. Switch on the oil supply.

- Switch on the electrical supply.
- Restart the boiler and run for 5 minutes.
- Recheck the CO<sub>2</sub> levels and if required, adjust the air shutter setting [4] to obtain the correct CO<sub>2</sub> level.

- Refit the sample point cap (hand tighten only, do not over tighten) and refit the burner cover.
- Complete the oil boiler commissioning checklist at the back of this manual.




Fig. 76

- [1] Bleed and pressure gauge port blanking plug
- [2] Pressure adjustment
- [3] Vacuum gauge port
- [4] Air shutter setting

**Nominal boiler rating at normal operating temperature using Kerosene (Class C2)**

| Nozzle                                    | Oil pump pressure |     | Fuel flow rate |      | Approx flue gas temp. °C | CO <sub>2</sub> % | Combustion head settings mm | Approx. air setting | Input (appliance) kW | Output (appliance) kW | Air damper disc setting | Flue damper required | Burner head             |
|---|-------------------|-----|----------------|------|--------------------------|-------------------|-----------------------------|---------------------|----------------------|-----------------------|-------------------------|----------------------|-------------------------|
|   | bar               | psi | Kg/h           | l/h  |                          |                   |                             |                     |                      |                       |                         |                      |                         |
| <b>Greenstar Heatslave II 12/18 model</b> |                   |     |                |      |                          |                   |                             |                     |                      |                       |                         |                      |                         |
| 0.40 x 80° EH                             | 8.5               | 123 | 1.12           | 1.38 | 67                       | 12.0              | 10.5                        | 2.3                 | 13.2                 | 13.0                  | A                       | Yes                  | BX & recirculation tube |
| 0.40 x 80° EH                             | 10.0              | 145 | 1.30           | 1.60 | 70                       | 11.5              | 11                          | 1.75                | 15.3                 | 15                    | B                       | Yes                  | BX & recirculation tube |
| 0.50 x 80° EH                             | 10.0              | 145 | 1.54           | 1.90 | 80                       | 12.0              | 11.5                        | 2.5                 | 18.3                 | 18.0                  | C                       | Yes                  | BX & recirculation tube |
| <b>Greenstar Heatslave II 18/25 model</b> |                   |     |                |      |                          |                   |                             |                     |                      |                       |                         |                      |                         |
| 0.50 x 80° EH                             | 10.0              | 145 | 1.54           | 1.90 | 76                       | 12.5              | 12.5                        | 1.5                 | 18.3                 | 18.0                  | N/A                     | Yes                  | BX                      |
| 0.60 x 80° EH                             | 8.8               | 128 | 1.84           | 2.28 | 81                       | 12.5              | 14                          | 2.25                | 21.9                 | 21.5                  | N/A                     | Yes                  | BX                      |
| 0.65 x 80° EH                             | 9.5               | 138 | 2.15           | 2.66 | 90                       | 12.5              | 15                          | 3.25                | 25.5                 | 25.0                  | N/A                     | Yes                  | BX                      |
| <b>Greenstar Heatslave II 25/32 model</b> |                   |     |                |      |                          |                   |                             |                     |                      |                       |                         |                      |                         |
| 0.65 x 80° EH                             | 9.8               | 142 | 2.15           | 2.66 | 79                       | 11.5              | 19                          | 3.5                 | 25.5                 | 25.0                  | N/A                     | No                   | BX                      |
| 0.75 x 80° EH                             | 10.3              | 150 | 2.46           | 3.04 | 84                       | 12.0              | 19                          | 4.25                | 29.1                 | 28.5                  | N/A                     | No                   | BX                      |
| 0.85 x 80° EH                             | 10.0              | 145 | 2.78           | 3.44 | 85                       | 12.5              | 19                          | 4.75                | 32.7                 | 32.0                  | N/A                     | Yes                  | BX                      |

Table 9 Combustion settings

## 6.4 Water treatment



### NOTICE:

- ▶ Salt based, softened water must not be used to fill the central heating system.

Ensure that the system has been cleaned. Refer to section 4.1 of these instructions.

### Inhibitor (Central Heating)

- ▶ Check drain cocks are closed and all radiator valves are open before adding a suitable inhibitor, or combined inhibitor/anti-freeze if the system is exposed to freezing conditions, to the heating system water in accordance with the manufacturers instructions.



The pH value of the system water must be between 6.5 and 8 or the appliance warranty will be invalidated.

- ▶ Record the date when the inhibitor was added to the system in the Boiler commissioning checklist and in the guarantee registration.



### NOTICE:

- ▶ The concentration of inhibitor in the system should be checked every 12 months or sooner if system content is lost.
- ▶ In cases where all attempts to find a micro leak have failed, Worcester, Bosch Group supports the use of Fernox F4 leak sealer.

### Water treatment products

Suitable water treatment products can be obtain from the following manufacturers:

|          |  |
|----------|--|
| ADEY     | 01242 546700<br><a href="http://www.adey.com">www.adey.com</a>                               |
| FERNOX   | 0330 100 7750<br><a href="http://www.fernox.com">www.fernox.com</a>                          |
| SENTINEL | 01928 704330<br><a href="http://www.sentinelprotects.com/uk">www.sentinelprotects.com/uk</a> |

### Appliance Drain Points

- ▶ The appliance can be drained via the primary heat exchanger point [4]:
  - There is an additional drain point on the secondary heat exchanger [1] with drain tube [2].
  - The heat bank also has a drain point [3]




Fig. 77 Appliance drains points

### Appliance manual vent points

- ▶ The appliance can be manually vented via:
  - The two vent points at the top of the secondary heat exchanger. Only one may be in use, the other may be obscured by side fluing.
  - A vent point on the primary flow from the primary heat exchanger.
- ▶ Use a radiator key or suitable screwdriver to open the vent point.




Fig. 78 Appliance manual vent points



## 6.5 Finishing commissioning - Appliance

1. Rotate the control box [A] towards you.  
Slide back into position [B].
2. Refit the top panel [C] and press down to compress the seal when fitting the securing screws at each corner.
3. Push the front panel up behind the top panel and push in at the base to secure with the latches [E] using the key [F] provided.

**Always apply pressure at the edges of the boiler panels when securing to avoid accidental damage.**




Fig. 79

### Handover

- ▶ Complete the Guarantee Registration Card, Combustion Record (at the rear of this manual) and CD11 or an equivalent commissioning form.
- ▶ Set up the controls and show the user how to operate all the controls shown in the User Guide and all system controls.
- ▶ Where applicable, instruct the customer how to re-pressurise the system.
- ▶ If the appliance is unused and exposed to freezing conditions, shut off all the mains supplies and drain the system and boiler.



Release drain point [G] to drain the secondary heat exchanger.

### 6.5.1 Appliance guarantee

This appliance has a guarantee against faulty materials or workmanship for a period from the date of installation subject to the following terms and conditions:

- During the period of this guarantee any appliance components that are proven to be faulty or defective in manufacture will be exchanged or repaired free of charge by Bosch Thermotechnology Ltd.
- The householder may be asked to prove the date of installation, that the appliance was correctly commissioned and, where appropriate, the first year's service has been carried out to the satisfaction of Bosch Thermotechnology Ltd., when requested. These should be documented as a part of the Boiler commissioning Checklist.
- The appliance has been used only for the normal domestic purposes for which it was designed.

This guarantee does not affect your statutory rights.

#### Guarantee registration

Your Greenstar appliance carries a guarantee against faulty material or manufacture subject to Terms and Conditions.

Guarantee Registration can be completed:

- On-line
  - You can register on our website:  
[www.worcester-bosch.co.uk/guarantee](http://www.worcester-bosch.co.uk/guarantee)
- By phone
  - You can register by ringing 0330 123 2552
- By post
  - Please send your completed form to:  
Worcester, Bosch Group, Cotswold Way, Warndon, Worcester, WR4 9SW.

To read the full Terms & Conditions please visit us on-line at [www.worcester-bosch.co.uk/guarantee](http://www.worcester-bosch.co.uk/guarantee).

Your statutory rights are not affected by the manufacturer's guarantee.

## 7 Service and spares

### 7.1 Inspection and service



**CAUTION:** Isolate the water, electricity and oil mains supplies before starting any work and observe all relevant safety precautions.



Do not use pressure washers or steam cleaners on this appliance or its cabinet.



**WARNING:** External equipment operated at 230 volts should not be serviced or repaired under adverse weather conditions

#### Routine servicing

To maintain efficient boiler operation, the following should be carried out at least once a year.

- ▶ Carry out a pre-service check and note any operational faults:

#### Pre-service checks

1. Release the latches at the base of the front panel using the key [J] provided, and pull towards you to remove.  
Store safely away from the working area.
- Operate the appliance and system and note any faults which may need to be corrected during the service.*
2. Pull the control box [A] all the way forwards.
    - Switch into service mode at switch [B].
  3. Unplug burner lead [C] from control box lead [D].
    - An adapter lead is available to allow mains voltage service aids to be operated from the service connection (Service lead Part No. 8 716 113 483 0).
  4. Swivel the expansion vessel [E] and support bracket out of the boiler taking care not to snag any electrical cables or kink the flexible hose.
  5. Loosen air duct pipe clip [F] and disconnect the air duct pipe.
  6. Unscrew burner retaining nut [G] and remove the burner and store safely away from the boiler.




Fig. 80

See the following instructions for detail of some of the service requirements listed below:

- ▶ Check and clean the burner.
- ▶ Replace burner nozzle and flexible oil hose/s.
- ▶ Check and clean the baffle retainers.
- ▶ Check and clean the baffles.
- ▶ Check that the flue damper is correctly fitted, if required.
- ▶ Check and clean the heat exchangers surfaces.
- ▶ Check the combustion chamber access door insulation board.
- ▶ Check that the flue system is unobstructed and clean as necessary.
- ▶ Clean or replace all oil filters.
- ▶ Check that the condensate system is not obstructed, clean and refill the condensate trap.
- ▶ The PRV is a safety device and must be checked for correct operation.  
The expansion vessel pressure must be checked and adjusted if necessary.

#### Clean the burner

- ▶ Remove the two hex head screws [1] and remove the air intake cover [2] and clear any debris from the air intake and air shutter.
- ▶ Remove the four screws [3] and remove the suction inlet [4] to gain access to the fan.
- ▶ Clean both sides of the fan and suction inlet cover with a brush and compressed air.
- ▶ Check the condition of the gaskets between these parts and replace if necessary.
- ▶ Note the position of the air shutter adjustment and check the air shutter moves freely.
- ▶ Check that the fan rotates freely.
- ▶ Reassemble the components.




Fig. 81 Fan access

#### Oil burner nozzle

Before removing or fitting a new nozzle refer to figure 82:

- ▶ Remove the screws [1] from the blast tube [2] and remove the blast tube



There is a recirculation tube fitted to the 12/18 models, this does not need to be removed from the blast tube

- ▶ Unplug the HT leads [4]
- ▶ Loosen the screw [3] securing the break plate [5] and slide the unit off
- ▶ Use a suitable spanner to stop the nozzle body turning
- ▶ Remove the nozzle [8] and secure the new nozzle, hand tight
- ▶ Tighten the nozzle utilising the two spanners used during removal, do not overtighten




Fig. 82 Nozzle access

Refer to figure 83 Photo cell alignment

- ▶ Refit the break plate [5] ensuring that the break plate is pushed fully on to the nozzle holder [6].
- ▶ To align the hole [9] in the break plate with the photocell, ensure that the fixing screw [3] is located fully in the seating [7] provided in the nozzle holder [6].




Fig. 83 Photocell alignment

- ▶ Reconnect the HT leads [4]
- ▶ Refit the blast tube [2] and secure with the screws [1]

Refer to figure 84:

- ▶ Check that the nozzle [1] and the electrode [2] alignment settings are correct.
- ▶ Ensure that the nozzle [1] is aligned centrally within the combustion head [3].
- ▶ Inspect for any visible defects.




Fig. 84 Nozzle and electrode alignment

### Pump filter

- ▶ Refer to figure 85 and remove the oil pump internal filter, clean in Kerosene and reassemble.

The internal filter is accessed by removing screws [1] and the oil pump cover [2].




Fig. 85 Pump filter access

- ▶ Replace the standard flexible oil line/s at every annual service to prevent the possibility of leakage due to ageing.
- ▶ Reassemble the burner components.
- ▶ Check the O-ring seal located around the combustion head and replace if necessary. This seal must be in good condition, seal failure will cause flue gases to escape into the room.

### External oil filter

- ▶ Remove the paper element from the external oil filter and replace it. If the filter contains a washable element, thoroughly clean in Kerosene and reassemble into the filter.

### Clean the boiler - Manifold access

Refer to figures 86.

- ▶ Release screws [1] to remove the flue manifold access cover [2] and clear any debris.
- ▶ Check the flue system and clean if necessary.
- ▶ Remove the baffle retainer [3] and baffles [4] from the secondary heat exchanger.
- ▶ Check and clean the secondary heat exchanger surfaces.



Do not use wire brushes or cleaning agents to clean the stainless steel secondary heat exchanger components.

- ▶ Check the condensate route [5] is clear.
- ▶ The condensate trap [7] should be removed and cleaned.
- ▶ Release the pipe locking tab [8] and disconnect the flexible pipe [9] from the top of the trap and move the flexible pipe up away from the trap.
- ▶ Release the trap locking tab [10] and move the trap up and back to remove from its mountings.
- ▶ Clean the trap by flushing with water.
- ▶ Check the O ring seals and replace if necessary, grease the seals with a solvent free grease.
- ▶ Refit the trap making sure that the locking tabs are locked in place.
- ▶ Pour 500 ml of water into drain [5] to refill the condensate trap and check that the condensate discharge pipe is discharging.
- ▶ Clean the secondary heat exchanger baffles [4] if necessary and refit correctly.
- ▶ Refit the baffle retainer [3].
- ▶ Check and clean the flue damper, ensure that it is correctly fitted
- ▶ Check the seal on the manifold access cover [6] and replace if necessary.

- ▶ Refit the flue manifold access cover [2] and secure with screws [1].





Fig. 86 Secondary heat exchanger and condensate trap detail

**Combustion chamber**

Refer to figure 87

- ▶ Remove the retaining nuts and washers [A].
- ▶ Remove combustion chamber/baffle access door [B].
- ▶ Check the fibreglass rope seal on the combustion chamber/baffle access door [B] and replace if necessary.
- ▶ Remove the one piece baffle set [C], clean and check the condition of the baffles. Replace baffle set if considered to be badly corroded/degraded.
- ▶ Thoroughly clean all of the heat exchanger surfaces using a suitable brush and clear all loose debris from the combustion chamber.
- ▶ Check the condition of the combustion chamber/baffle access door insulation. If the insulation is damaged the door assembly must be replaced.
- ▶ Ensure one piece baffle set [C] is in the right location [D], correctly resting on the baffle rests [F] on either side of the combustion chamber and pushed securely into place.  
Baffle sets for the 18/25 and 25/32 boilers are identified with tabs on the front and rear edge
- ▶ Refit combustion chamber door [B].

**NOTICE:**  Secure with nuts and washers [A] and tighten until the chamber door is firmly secured, do not over tighten the nuts.

**Fire valve**

- ▶ Check that the oil supply pipe has a fire valve fitted externally to the building and appliance with the fire valve sensor located within the appliance case. A fire valve sensor clip [E] is provided for this purpose.





Fig. 87

 18/25 and 25/32 baffle are identified with tabs on the front and rear edges




Fig. 88 Baffle arrangement




Fig. 89 Baffle location

### Re-commission the burner



**WARNING: Flue gas leakage.**

The seal between the burner and the mounting flange must form a gas tight seal to prevent leakage of potentially dangerous gases from the combustion chamber.

- ▶ Unless the burner is level when pushing the burner into the flange the O ring may not seat properly allowing flue gas to escape!
- ▶ Always check that the O-ring seal (Fig. 90 item A) is in good condition before fitting the burner. Replace the O-ring seal if defective.




Fig. 90 18/25 and 25/32 Burner O-ring seal shown

Refer to figure 91:

1. Align burner combustion head into the boiler collar.
  - ▶ Locate the burner retainer [A] over the threaded lug on the collar [B], ensure that the burner is level and push the burner firmly onto the flange ensuring the O-ring seal is fully engaged. Support the burner in position and secure with the retaining nut [C]. Tighten sufficiently to hold the burner but do not over tighten.

- ▶ Check that the burner is seated correctly on its mounting flange and that the oil hose/s are routed correctly as shown in Fig. 40 on page 27 and not trapped in front of or underneath the burner.
  1. Refit the flexible air duct and secure with clip [D].
  2. Swivel the expansion vessel [F] back into position taking care not to kink the flexible hose or snag electric cables.
  3. Plug the burner lead [G] into the connector [H].
- ▶ Connect an oil pressure gauge to the oil pump, run the burner and check the oil pressure is correct for the required boiler output. Check that the smoke reading is between 0 and 1, if the smoke reading is above one check the air setting. If the air setting is correct check that the burner has been reassembled correctly. Allow the boiler to warm up then check the combustion settings are correct as indicated in table 9, adjust the CO<sub>2</sub> if necessary using the air shutter. When the combustion is correct turn off the boiler, remove the pressure gauge and refit the blanking plug and plastic cover.

### Refit control box

5. Rotate the box towards you [J].
  - ▶ Slide control box drawer back into position.

### Refit panels

6. Refit the top panel [K] and press down to compress the seal when fitting the securing screws at each corner.
7. Push the front panel [L] up behind the top panel and push in at the base and secure with the key [N] and latch [M].



Always apply pressure at the edges of the boiler panels when securing to avoid accidental damage.

### After service handover

- ▶ Make a note of the date of any water treatment.
- ▶ Set the controls back to the users requirements.
- ▶ Complete the service interval record at the back of this manual and a CD11 or an equivalent form.
- ▶ If the appliance is unused and exposed to freezing conditions; shut off all the mains supplies, isolate the boiler and drain the system and boiler, including the secondary heat exchanger.




Fig. 91

**Spares**


For Worcester Bosch spares refer to the the website at [www.worcesterbosch.co.uk/spares](http://www.worcesterbosch.co.uk/spares)

## 8 Fault finding and diagnosis

### 8.1 Status cause codes

These cause codes are displayed during the normal operation of the boiler. They are not faults, they just give information on the current status of the boiler in real time.

#### Cause code

 During normal operation various status codes can be displayed by pressing the service button.

The first screen of the information menu displays the current status code, this will change as the boiler runs through the various modes and sequences.

| Cause code |                            |   |
|------------|----------------------------|---|
| 200        | CH active                  | The Central Heating system is being heated.   |
| 201        | DHW active                 | The Domestic Hot Water is being heated/<br>tank is being heated.  |
| 202        | CH Anti rapid-cycle mode   | Time delay to prevent rapid-cycling of the boiler on the room thermostat.   |
| 203        | System stand-by            | The boiler has no CH or DHW demands.  |
| 270        | Power up mode              | The boiler is ON, warming up and running self check routines. This lasts approximately 35 seconds.  |
| 358        | Three way valve anti-seize | Anti-seize operation. If the diverter valve has not moved in 24 hours, the valve is operated to prevent seizing, duration approximately 10 seconds. |

Table 10

### 8.2 Information menu





#### Selecting the Information Menu

The Information Menu is a "read only" menu. Information about the boiler is displayed here, some of the values are updated in real time to give the current status of the boiler.

All menus time-out after 2 minutes and the display returns to the normal operation display, the display backlight turns off after another 30 seconds and goes into stand-by mode.

Double up or down arrows indicate that the menu can only be scrolled up or down, an up arrow combination indicates position in the menu where options can be scrolled either up or down.

#### To enter the Information Menu

- Press the  button to enter the Information Menu.
  - A 3 figure boiler status code will be displayed alongside the Information Menu number. Refer to page 36 for a description of the boiler status codes.
- Use the  and  arrow buttons to scroll through the menu items.
- Press the  button again to exit the Information Menu.




Fig. 92

#### Information Menu listing

|     |                               |   |
|-----|-------------------------------|---|
| i1  | Current status                | Every operation and mode of the boiler has a related boiler status code. The boiler status code is displayed on the screen as a 3 figure number. Refer to page 36 or error table for information on the boiler status code. |
| i2  | Last error                    | This can be viewed during normal operation. Displays the last diagnostic code with boiler status code.  |
| i3  | Maximum CH output             | The maximum possible CH output is displayed in kW.  |
| i4  | Maximum DHW output            | The maximum possible DHW output is displayed in kW.   |
| i6  | DHW flow rate                 | The screen displays the current DHW flow rate in 0.1 l/m units.   |
| i7  | CH flow temperature set point | This is the temperature set point for the primary flow from the main heat exchanger. This will be zero during CH demand.  |
| i9  | Flow temperature              | This is the actual temperature from the main heat exchanger displayed in real time (rounded to 0.5°C units).  |
| i10 | Maximal temperature           | This is the current temperature from the "maximal safety sensor" displayed in real time (rounded to 0.5°C units). The sensor is mounted on the top of the primary heat exchanger.   |
| i11 | DHW flow temperature          | Current DHW flow temperature displayed in real time (rounded to 0.5°C units).   |
| i12 | DHW temperature set point     | This is the thermal store temperature set point, selected via the Hot Water control knob on the fascia, (rounded to 0.5°C units).   |

Table 11

|     |                                   |   |
|-----|-----------------------------------|---|
| i13 | Thermal store current temperature | This is the thermal store current temperature, displayed in real time (rounded to 0.5°C units).   |
| i14 | DCW inlet temperature             | Current DCW inlet temperature displayed in real time (rounded to 0.5°C units).  |
| i15 | Out door temperature              | This is the out door temperature displayed in real time (rounded to 0.5°C units). Only available if a Weather Compensation sensor has been fitted and Weather Compensation is active. |
| i19 | Time inputs                       | This indicates the status of the optional fascia mounted controls:<br>0 = CH off, DHW off<br>1 = CH off, DHW on<br>2 = CH on, DHW off<br>3 = CH on, DHW on                            |
| i20 | Software version                  | CBS software version of main PCB.   |
| i21 | Software version                  | HIS software version of the HIS PCB.  |
| i22 | HCM number                        | HCM last 3 digits displayed:<br>391 = 12/18 kW<br>390 = 18/25 kW<br>301 = 25/32 kW  |
| i23 | HCM version number                | For example "4"   |

Table 11

### 8.3 Service menus

#### Selecting Service Menus

- Press and hold the and buttons together for 1 second, the display will show Menu 1.
  - Double up or down arrows indicate that the menu can only be scrolled up or down, an up and down arrow combination indicates positions in the menu where options can be scrolled either up or down.




Fig. 93

- Scroll up and down through the menus with the and arrow buttons on the right hand side of the display.




Fig. 94

#### Menu 1 system parameters

Initially Menu 1 will be displayed.

|             |                                    |                                 |
|-------------|------------------------------------|---------------------------------|
| <b>1.W1</b> | Weather Compensation Functionality | Enable.                         |
| <b>1.W2</b> | Weather Compensation Functionality | Point A (@-10°C)                |
| <b>1.W3</b> | Weather Compensation Functionality | Point B (@+20°C)                |
| <b>1.W4</b> | Weather Compensation Functionality | System frost protection enable. |

#### Menu 2 boiler parameters

- Select Menu 2 via the arrow buttons.




Fig. 95

- Press and hold the button for 1 second to enter Menu 2.
  - The menu lists the boiler parameters, that can be adjusted in this menu.
  - To modify the setting, select the desired menu option and press the button, the option will flash.
  - Adjust the parameter using the arrow buttons and press the button to confirm.
    - A will display for 3 seconds to confirm the update of the new value.






Fig. 96

|  |  |
|--|--|
| <b>2.7A</b> Demand/fault LED (blue light) activation | 0 = The blue light will only operate as a flashing fault alert.  |
|  | 1 = The blue light will operate as a boiler operation and fault alert.<br>This is set to 1 by default. |

**i** Menus 3 and Test are empty and are not used on this appliance.

## 8.4 Factory reset and fault codes

### 8.4.1 Factory reset

To reset changes made in Menu 2 back to the factory default setting:

**i** Any changes made to Menu 1 are not reset by these actions.




Fig. 97

1. Press and hold the and buttons for at least 5 seconds. The screen will then display code 8E with the spanner symbol.

2. Press the button and "reset" will be displayed with the tick symbol for 3 seconds. After 3 seconds the display will revert to the normal operation screen.




Fig. 98

### 8.4.2 Locking or Blocking fault conditions

Should a fault develop with this boiler (or the system), the boiler will enter into a Locking or Blocking condition.

#### Locking condition

- The boiler display will flash a warning triangle.
- A 3 digit **cause code** will flash on the display during a Locking error.
- An alpha numeric **fault code** will be displayed indicating the fault group.

Manual intervention is required following clearance of the fault.

- ▶ Press the reset button on the boiler fascia.

#### Blocking condition

- The boiler will stop operating and no fault code will be displayed.
- An alpha numeric **fault code** is accessed in the info menu by pressing the spanner/return button.

**i** Unlike a Locking error, during a Blocking error (or normal operating status), a fault code is not automatically displayed.

- A 3 digit cause code is also accessed in the info menu by pressing the spanner/return button.
- The condition will clear automatically when the associated fault clears e.g. waiting for an area of the boiler to cool down.
- In some cases a Blocking error has a defined time duration prior to changing to a Locking condition.

8.4.3 Cause and fault codes

| Cause code | Fault code | Description  | Reset type         | Blocking | Locking | Possible cause   |
|------------|------------|--|--------------------|----------|---------|--|
| 210        | E9         | Maximum temperature thermostat or air pressure switch activated      | Reset              |          | X       | Flue gas or tank thermostat overheat. Reset the overheat thermostat or air pressure switch before resetting appliance.   |
| 212        | No code    | Safety or flow temperature rises too high                            |                    | X        |         | Air lock or reduced water content.   |
| 218        | E5         | Flow temperature too high  | Reset              |          | X       | Primary sensor overheated.   |
| 219        | E9         | Safety temperature too high  | Reset              |          | X       | The main heat exchanger has overheated. Maximum temperature 105°C.   |
| 220        | E9         | Safety sensor short circuit  | Reset              |          | X       | Maximum temperature sensor on the main heat exchanger has failed.  |
| 221        | E9         | Safety sensor open circuit   | Reset              |          | X       | Maximum temperature sensor on the main heat exchanger has not been recognised.   |
| 222        | E2         | Flow sensor short circuit  | Reset              |          | X       | Flow sensor shorted or damaged.  |
| 223        | E2         | Flow sensor open circuit   | Reset              |          | X       | Flow sensor disconnected or damaged.   |
| 233        | E2         | HCM (Heat Control Module)  | Reset              |          | X       | HCM Code plug missing or defective.  |
| 237        | F0         |  | Reset              |          | X       | Resistors between plug X4 pins 3 & 5 disconnected/>150k Ω or water in the burner control box   |
| 238        | F0         |  | Reset              |          | X       | Resistors between plug X4 pins 3 & 5 disconnected/>150k Ω or water in the burner control box   |
| 239        | F0         | Watchdog error   | Reset              |          | X       |  |
| 259        | F0         | AD reference error   | Reset              |          | X       |  |
| 263        | F0         | Appliance powered off with locking fault present                     | Reset              |          | X       | Locking fault present when powered off.  |
| 271        | D4         | Temperature difference between flow and safety sensors exceeds limit |                    | X        |         | The temperature of the primary flow and the safety sensor on the main heat exchanger should be within 15°C of each other.  |
| 276        | E9         | Flow temperature exceeds 95°C  |                    | X        |         | Primary overheat - boiler waits for temperature to reduce, approximately 30 minutes.   |
| 277        | E9         | Safety temperature exceeds 95°C                                      |                    | X        |         | Main heat exchanger safety sensor overheat - boiler waits for temperature to reduce, approximately 30 minutes.   |
| 278        | F0         | Sensor test error  | Reset              |          | X       | On power up, all safety sensors are checked. Check has failed.   |
| 279        | F0         | AD converter error   | Reset              |          | X       |  |
| 290        | F0         | AD converter reference error   | Reset              |          | X       |  |
| 332        | E5         | Primary flow has exceeded 105°C                                      | Reset              |          | X       | Primary sensor overheated.   |
| 359        | No Code    | DHW outlet or storage tank exceeds 90°C                              |                    | X        |         | Pump & burner are blocked until temperature drops to <89°C.  |
| 360        | 9A         | Incorrect HCM for boiler variant                                     |                    | X        |         |  |
| 380        | No code    | Inlet DCW temperature higher than DHW outlet temperature             |                    | X        |         | The output is blocked until the inlet temperature drops below the output temperature.  |
| 808        | A7         | DHW sensor defective   | Reset              |          | X       |  |
| 809        | A0         | Thermal store sensor defective                                       | Reset              |          | X       |  |
| 855        | 9F         | Burner lock out  | Reset              |          | X       | Check the burner and fuel supply. Ensure the oil supply is free of contaminants.   |
| 856        | 9F         | 4 burner lockouts repeated resets                                    | Turn boiler off/on |          | X       | After Four 855 burner lock outs in one demand period, cause code 856 is displayed.<br>After boiler off/on cause code 263 will be displayed, press the reset button to clear this fault. another 4 burner lock resets can be attempted. |

Table 12 Cause and fault codes

| H code | Displayed symbols   | Cause   |
|--------|---|---|
| H29    | Warning triangle and House symbol displayed on controller | Weather compensation activated but no weather sensor detected, refer to section 5.11 on page 32 for more information. |
| H27    | Warning triangle symbol displayed on controller           | DCW in sensor defect, (appliance operation not affected)  |

Table 13 H fault codes

**8.5 DHW function chart**




Fig. 99

### 8.6 CH function chart




Fig. 100

**i** Numbers in square brackets are the cause code of the current appliance operation, visible in the service menu slot 1 (i1),

| Key                          |  |
|------------------------------|--|
| <b>3WV</b>                   | 3 way valve (diverter valve).  |
| <b>CH set point</b>          | The target flow temperature set on the CH fascia control knob.   |
| <b>CH adaptive offset</b>    | The learnt offset temperature applied to the CH flow so that the peak flow temperature after burner OFF = CH set point.  |
| <b>Anti fast cycle delay</b> | To stop the appliance short cycling if a room stat is intermittently calling or is poorly positioned, there is a 10 minute delay for CH demands timed from the last CH demand end. |

### 8.7 Protection functions





Fig. 101




6720805209-73-1Wo

Fig. 102

| Key |  |
|-----|--|
| PHE | Primary heat exchanger.                        |
| 3WV | 3 way valve (diverter valve).                  |
| FS  | Appliance connection frost stat supply (230 V) |
| FR  | Appliance connection frost stat return (230 V) |

### 8.8 Solar compatibility



6 720 805 209-74.1TL

Fig. 103

- [1] Normal operation: the tank will cool more slowly for the same DHW performance if the DCW is above normal DCW temperature, thus saving fuel.
- [2] Solar tank hot: therefore the burner will not be required at high DHW flow rate and the tank will boost the solar heated water if the temperature drops.
- [3] Solar tank will satisfy the DHW requirements: therefore the appliance allows the water to pass straight through without taking any action apart from monitoring the temperatures. To utilise the solar panels to their maximum potential, the solar tank thermostat will need to be set high and the Heatslave II DHW setting low.
- [4] Solar tank overheat: DCW above solar tank limit, appliance will not operate pump or burner and fault code will be displayed within the service menu.

### 8.9 Burner diagnostics mode

Service/installation engineers only.

To access the Burner control box diagnostics or to use the burner reset button to reset the burner, the burner diagnostic mode must be activated as follows:




Table 14



The burner diagnostics mode can be manually exited at any time when the burner is locked out by holding down the service mode button whilst pressing the controls reset button.

**Fault code 9F 856:** If burner lockout is reset 4 times in one demand period using the fascia reset button the controls will lockout with a new code: 9F 856. This is to protect the burner components against over use of the reset and requires a power down of the appliance to reset. The burner control box also has this facility, if the reset button is operated 4 times the burner control box will not reset until the power has been interrupted to the burner.

### 8.10 Riello digital control boxes

#### 8.10.1 Control box LED codes

| Lockout types (burner in lockout)  |                     |
|--|---------------------|
| RED steady ON<br>Lockout for no flame after safety time  | [3]                 |
| RED 0.5 seconds ON/ RED 0.5 seconds OFF<br>Lock out for false flame signal                     | [5a]                |
| RED 0.2 seconds ON /RED 0.2 seconds OFF<br>Lock out for maximum number of flame loss re-lights | [9]                 |
| RED 2.5 seconds ON / ORANGE 0.5 seconds ON<br>Lock out for fan motor failure                   | [3d]                |
| RED 2.5 seconds ON / GREEN 0.5 seconds ON<br>Lock out for oil valve circuit driver failure     | [8c]                |
| ORANGE 0.5 seconds ON / GREEN 0.5 seconds ON<br>Lock out for EEPROM failure                    | Replace control box |
| Red 0.5s ON / Red 2.5s OFF<br>Max pre-heat time exceeded (10 minutes)                          | [2]                 |

Table 15

| Anomaly types (Burner in stand-by)                                      |   |
|---|---|
| Green 0.5 s ON / Green 2.5 s OFF<br>Pre-heating time                    | Fit pre-heat link   |
| Green 0.5s ON / RED 0.5s ON<br>Extraneous light                         | Lock out after 25s  |
| Orange steady ON<br>Abnormal frequency supply                           | When an anomaly appears during:<br>▶ pre-purge. the burner remains in pre-purge.<br>▶ after ignition, burner remains in operation.<br>When anomalies disappear the burner re-starts |
| Orange 0.2s ON / Green 0.2s ON<br>Control box internal error            |   |
| Green 0.2s ON / Red 0.2s ON<br>Reset pushbutton or remote reset failure | Remote reset / pushbutton is activated for more than 60 seconds.<br>When anomaly appears the burner does not stop   |

Table 16

**Last lockout memory feature**

The control box allows the last lockout that happened to be displayed.

Access to this function is possible in both STANDBY and OPERATING status.

- ▶ Keep the button pressed for 25 seconds =  $t < 30$  seconds

- ▶ Release the button.

LED displaying the type of lockout memorised for 10 seconds

The time displaying the type of lockout can be extended by pressing the reset button again during the display of the lockout (the lock out display continues for another 10 seconds)

**8.10.2 Fault finding**

| Line | Check   | Action   |   |   |
|------|---|--|---|---|
| 1    | Control box is supplied with heat demand?   | Yes  | Go to line 2                            |   |
|      |   | No   | Check boiler and system controls        |   |
| 2    | Is the pre-heater fitted or if no pre-heater is fitted, is the link fitted?               | Yes  | Go to line 3                            |   |
|      |   | No   | Fit the Pre-Heater or link              |   |
| 3    | Motor starts after initialization check time 3.5 seconds?                                 | Yes  | Go to line 4                            |   |
|      |   | No   | Go to line 3a                           |   |
|      | 3a  | Green 0.5 seconds ON/Red 0.5 seconds ON before lockout?                      | Yes                                     | Go to line 5a                           |
|      |   |  | No                                      | Go to line 3b                           |
|      | 3b  | Fan motor or oil pump seized?  | Yes                                     | Replace seized component                |
|      |   |  | No                                      | Go to line 3c                           |
|      | 3c  | 230 Volts to motor across blue and black motor wires?                        | Yes                                     | Go to line 3d                           |
|      |   |  | No                                      | Replace control box                     |
| 3d   | Approximately 35 $\Omega$ across blue and black motor wires?                              | Yes  | Replace motor capacitor                 |   |
|      |   | No   | Replace fan motor and check control box |   |
| 4    | Motor runs for less than 12 seconds?  | Yes  | Go to line 4a                           |   |
|      |   | No   | Go to line 5                            |   |
|      | 4a  | Motor gives 50 Volts a.c. across black and white wires?                      | Yes                                     | Replace control box                     |
|      |   |  | No                                      | Replace fan motor                       |
| 5    | Burner does not fire, burner locks out after 25 seconds from motor start?                 | Yes  | Go to line 5a                           |   |
|      |   | No   | Go to line 6                            |   |
|      | 5a  | Burner fires when the photo cell is covered?                                 | Yes                                     | Remove extraneous light                 |
|      |   |  | No                                      | Go to line 5b                           |
| 5b   | Photo cell voltage $\geq 3.8V$ in the dark and approximately 1.2V in the light?           | Yes  | Replace the control board               |   |
|      |   | No   | Replace the photo cell                  |   |
| 6    | Pump washing pressure 1 to 2 bar?   | Yes  | Go to line 7                            |   |
|      |   | No   | Go to line 6a                           |   |
|      | 6a  | Pump pressure more than 6 bar?   | Yes                                     | Replace oil pump                        |
|      |   |  | No                                      | Go to line 6b                           |
|      | 6b  | Check oil supply to the pump, if oil supply is OK                            | Go to line 6c                           |   |
|      | 6c  | Drive coupling broken?   | Yes                                     | Replace drive coupling                  |
| No   |   |  | Replace oil pump                        |   |
| 7    | Ignition spark present?   | Yes  | Go to line 8                            |   |
|      |   | No   | Go to line 7a                           |   |
|      | 7a  | Are ignition leads and electrodes OK and set correctly?                      | Yes                                     | Replace control box                     |
|      |   |  | No                                      | Replace/reset electrodes/ignition leads |
| 8    | Solenoid coil releases working pressure?  | Yes  | Go to line 9                            |   |
|      |   | No   | Go to line 8a                           |   |
|      | 8a  | Does burner light or green 0.5 seconds ON/red 0.5 seconds ON before lockout? | Yes                                     | Go to line 5a                           |
|      |   |  | No                                      | Go to line 8b                           |
|      | 8b  | Contaminated fuel filters?   | Yes                                     | Clean/Replace filters                   |
|      |   |  | No                                      | Go to line 8c                           |
|      | 8c  | Coil lead OK   | Yes                                     | Go to line 8d                           |
|      |   |  | No                                      | Replace solenoid coil lead              |
|      | 8d  | Solenoid coil resistance 90 to 110 $\Omega$                                  | Yes                                     | Go to line 8e                           |
|      |   |  | No                                      | Replace solenoid coil                   |
| 8e   | After 15 seconds from motor start, 25 to 30 Volts d.c. to solenoid coil? (coil connected) | Yes  | Replace oil pump                        |   |
|      |   | No   | Replace control box                     |   |

Table 17

| Line | Check                                     | Yes   | Action                                    |                                   |
|------|---|---|---|-----------------------------------|
| 9    | Air set correctly?                        | Yes   | Go to line 10                             |                                   |
|      |   | No  | Adjust combustion air settings            |                                   |
| 10   | Does the burner light?                    | Yes   | Go to line 11                             |                                   |
|      |   | No  | Go to line 10a                            |                                   |
|      | 10a                                       | Is the nozzle atomising the fuel?   | Yes                                       | Go to line 11                     |
|      |   |   | No  | Go to line 10b                    |
|      | 10b                                       | Nozzle new?   | Yes                                       | Go to line 10c                    |
|      |   | No  | Replace nozzle                            |                                   |
| 10c  | Check oil pipe from pump to nozzle holder |   | Clean/ replace pump and fuel line filters |                                   |
| 11   | Combustion head set correctly?            | Yes   | Go to line 11a                            |                                   |
|      | Flue damper fitted? (if required)         | No  | Reset combustion head                     |                                   |
|      | 11a                                       | Flame goes out then re-lights   | Yes                                       | Go to line 11c                    |
|      |   |   | No  | Go to line 11b                    |
|      | 11b                                       | Boiler or flue blocked  | Yes                                       | Clear blockage                    |
|      |   |   | No  | Go to line 11c                    |
|      | 11c                                       | If balanced flue, remove the snorkel and test - now OK?                         | Yes                                       | Go to line 11d                    |
|      |   |   | No  | Go to line 11e                    |
|      | 11d                                       | Balanced flues can recirculate gases causing recycling                          |   | Check the flue position and seals |
|      | 11e                                       | Photo cell voltage $\geq 3.8V$ in the dark and approximately 1,2V in the light? | Yes                                       | Replace the control box           |
| No   |   |   | Replace photocell                         |                                   |

Table 17

### 8.11 Flame sensing photocell

#### Digital photocell

To check the correct functioning of the photocell, perform the following actions:

- ▶ Electrically isolate the burner
- ▶ Remove the photocell
- ▶ Connect a voltmeter across the blue and brown wires to the photocell
- ▶ Reconnect the power to the burner and wait until the burner locks out due to the false flame fault (red and green LEDs blinking)
- ▶ Cover the photocell to exclude any light and the voltmeter should read 3.8 Volts or higher
- ▶ Expose the photocell to light and the voltmeter should read approximately 1.2 Volts
- ▶ If these two conditions are not met, change the photocell
- ▶ Disconnect the voltmeter
- ▶ Disconnect the burner and replace the photocell


### 8.12 Oil supply vacuum testing

A vacuum gauge can be attached to the oil pump vacuum test port [1] and the boiler operated to check the vacuum readings. Oil pumps can operate if readings are between plus 0.4 bar and minus 0.35 bar.

This means oil tanks can be 4 metres higher (to top of oil) or 3.5 metres lower (if fitted with a de-aerator or two-pipe oil delivery system) than the oil pump.

If vacuum is greater than minus 0.35 bar then you must also check that the oil supply is not obstructed and that the oil supply pipe is correctly sized.

Accessory 8-716-116-333-0 is available to assist in connecting a vacuum gauge to the vacuum test port.



6720821683-21.1Wo

Fig. 104 Oil pump ports/connections

- [1] Pressure adjuster
- [2] Vacuum gauge port
- [3] Bleed and pressure gauge port
- [4] Return connection
- [5] Inlet connection
- [6] Auxiliary pressure gauge port

### 8.13 Air pressure switch, flue overheat reset and tank overheat reset

This is a blocking error that must be reset by pressing thermostat reset button or air pressure switch reset button.

If the flue-gas temperature exceeds the cut-off point or the flue is restricted, the appliance will lockout indicated by code E9 210 [1]

- ▶ Press the flue-gas thermostat reset button [3], located on the underside of the support bracket [2].

-or-

If the pressure differential between the flue inlet and exhaust exceeds a certain value the appliance will lockout indicated by code E9 210 [1]

- ▶ Press the air pressure reset button [4], located on the underside of the support bracket [2].

-or-

If the tank exceeds a set temperature value the thermostat will trip.



- ▶ Remove the screws securing the cover [1]
- ▶ Remove the cover [2]
- ▶ Press the black reset button
- ▶ Replace the cover and secure with the screws




Fig. 105

- [1] Error display
- [2] Boiler cross brace
- [3] Flue overheat reset
- [4] Air pressure reset




Fig. 106 Tank overheat reset

- [1] Screws
- [2] Overheat thermostat cover
- [3] Black reset button

### 8.14 Air pressure switch connections



**NOTICE:** APS pressure sensing tubes

- ▶ Ensure that the pressure sensing tubes are not kinked or trapped when working on the boiler.
- ▶ Kinked or trapped tubes will prevent the APS from functioning correctly



**Air pressure switch sensing tube connections:**

- ▶ Ensure that the sensing tubes are connected correctly, refer to figure 107




Fig. 107 Sensing tube connections

- [1] Air pressure switch
- [2] Air intake connection (front connection)
- [3] Flue exhaust connection (rear connection marked with a +)

### 8.15 System gassing



**WARNING:** If you suspect the heating system is gassing, you must exercise caution when carrying out testing or remedial work as the gasses produced can be flammable.

Do not vent air from radiators whilst the central heating is switched on. Allow 30 minutes after venting the radiators before using the central heating or hot water.


- ▶ Whilst venting radiators, do not allow the pressure in the boiler to drop below the point at which it is normally set.
- ▶ If the system is to be drained, the boiler must be electrically isolated.



**CAUTION:** If the system pressure is repeatedly increasing, even when the appliance is not operating, you should first check that the filling link is fully closed and confirm that it is not passing.

If the radiators are also not heating to the top of the panels and repeatedly need venting, the system may be suffering from gassing. This is an indication that corrosion is taking place and requires the system being cleaned and treated to BS7593.

- ▶ This should be confirmed by taking water samples to check pH levels and turbidity.
- ▶ Failure to properly maintain the heating system may result in damage to the system and appliance, and may affect the boiler warranty.



0010036323-001

Fig. 108

**8.16 Oil appliance commissioning checklist**

This Commissioning checklist is to be completed in full by the competent person who commissioned the appliance as a means of demonstrating compliance with the appropriate Building Regulations and then handed to the customer to keep for future reference.



**IMPORTANT**

▶ Leave this manual with the Homeowner.

**Appliance details**

Appliance make and model: \_\_\_\_\_  
 Appliance serial number: \_\_\_\_\_

**Commissioning Engineer**

Company name: \_\_\_\_\_  
 Company address: \_\_\_\_\_  
 Telephone number: \_\_\_\_\_  
 Commissioned by (signature) \_\_\_\_\_  
 (print name) \_\_\_\_\_  
 Commissioning date: \_\_\_\_\_

**Commissioning checks**

|                           |                              |
|---------------------------|------------------------------|
| Oil type used is Kerosene | Yes <input type="checkbox"/> |
| Pump pressure             | PSI                          |
| CO <sub>2</sub>           | %                            |
| CO                        | ppm                          |
| CO/CO <sub>2</sub> ratio  |                              |
| Smoke reading             |                              |
| Flue gas temperature      | °C                           |
| Flue pressure             |                              |
| Burner model:             |                              |

**Controls: Tick the appropriate boxes**

|  |  |                          |                              |                          |
|--|--|--------------------------|------------------------------|--------------------------|
| Time and temperature control to heating  | Room thermostat and programmer/timer     | <input type="checkbox"/> | Programmable room thermostat | <input type="checkbox"/> |
|  | Load/Weather compensation                | <input type="checkbox"/> | Optimum start control        | <input type="checkbox"/> |
| Time and temperature control hot water   | Cylinder thermostat and programmer/timer | <input type="checkbox"/> | Combination boiler           | <input type="checkbox"/> |
| Heating zone valves                      | Fitted                                   | <input type="checkbox"/> | Not required                 | <input type="checkbox"/> |
| Hot water zone valves                    | Fitted                                   | <input type="checkbox"/> | Not required                 | <input type="checkbox"/> |
| Thermostatic radiator valves             | Fitted                                   | <input type="checkbox"/> | Not required                 | <input type="checkbox"/> |
| Automatic by-pass valve fitted to system | Fitted                                   | <input type="checkbox"/> | Not required                 | <input type="checkbox"/> |
| Boiler interlock                         |  |                          | Provided                     | <input type="checkbox"/> |

**All Systems**

The system has been flushed and cleaned in accordance with BS7593 and appliance manufacturer's instructions? Yes

What system cleaner was used? \_\_\_\_\_

What inhibitor was used? \_\_\_\_\_ Quantity  litres

Has a system filter been fitted? Yes  No

The condensate drain has been installed in accordance with the manufacturer's instructions and/or BS5546/BS6789? Yes

If the condensate pipe terminates externally has the pipe diameter been increased and weatherproof insulation fitted? Yes

**Central Heating mode: Measure and record**

Central Heating flow temperature  °C      Central Heating return temperature  °C

**Domestic Hot Water mode: Measure and record**  
**Combination boilers only**

Is the installation in a hard water area (above 200ppm)? Yes  No

If yes, has a water scale reducer been fitted? Yes  No

What type of scale reducer has been fitted? \_\_\_\_\_

Cold Water Inlet temperature  °C      Hot Water Outlet temperature  °C

Water flow rate  l/min

**All installations**

Fire valve fitted rated to 85 °C. Yes

Is the oil tank and supply clean and free from contamination? Yes  No

Is the flue damper correctly fitted? Yes  No

Are the hoses from the Air pressure switch correctly routed and free from kinking? Yes  No

Is a solid non-combustible surface large enough to accommodate the appliance provided? Yes  No

Does the installation comply with current OFTEC Regulation? Yes  No

The heating and hot water system complies with the appropriate Building Regulations? Yes  No

The appliance and associated products have been installed and commissioned in accordance with the manufacturer's instructions? Yes  No

The operation of the appliance and system controls have been demonstrated to and understood by the customer? Yes  No

### 8.17 Service interval record

It is recommended that your appliance is serviced annually and that the Service Interval Record is completed and signed. Before completing the service Interval record below, ensure that you have carried out the service functions described in this manual. Always use the manufacturer's recommended spare parts

|                                       |  |  |                          |
|---------------------------------------|--|--|--------------------------|
| <b>Service 1</b>                      |  | Date:  |                          |
| Engineer's name:                      |  |  |                          |
| Company name:                         |  |  |                          |
| Telephone number:                     |  |  |                          |
| Registration number:                  |  |  |                          |
| Fire valve inspected (rated to 85 °C) |  | Yes <input type="checkbox"/> No <input type="checkbox"/> |                          |
| Nozzle changed?                       | Yes <input type="checkbox"/> No <input type="checkbox"/> | Pump pressure:   | psi                      |
| CO <sub>2</sub>                       | CO   | ppm  | CO/CO <sub>2</sub> ratio |
| F.G.T.                                | °C   | Flue pressure:   |                          |
| Comments:                             |  |  |                          |
| Signature:                            |  |  |                          |

|                                       |  |  |                          |
|---------------------------------------|--|--|--------------------------|
| <b>Service 3</b>                      |  | Date:  |                          |
| Engineer's name:                      |  |  |                          |
| Company name:                         |  |  |                          |
| Telephone number:                     |  |  |                          |
| Registration number:                  |  |  |                          |
| Fire valve inspected (rated to 85 °C) |  | Yes <input type="checkbox"/> No <input type="checkbox"/> |                          |
| Nozzle changed?                       | Yes <input type="checkbox"/> No <input type="checkbox"/> | Pump pressure:   | psi                      |
| CO <sub>2</sub>                       | CO   | ppm  | CO/CO <sub>2</sub> ratio |
| F.G.T.                                | °C   | Flue pressure:   |                          |
| Comments:                             |  |  |                          |
| Signature:                            |  |  |                          |

|                                       |  |  |                          |
|---------------------------------------|--|--|--------------------------|
| <b>Service 5</b>                      |  | Date:  |                          |
| Engineer's name:                      |  |  |                          |
| Company name:                         |  |  |                          |
| Telephone number:                     |  |  |                          |
| Registration number:                  |  |  |                          |
| Fire valve inspected (rated to 85 °C) |  | Yes <input type="checkbox"/> No <input type="checkbox"/> |                          |
| Nozzle changed?                       | Yes <input type="checkbox"/> No <input type="checkbox"/> | Pump pressure:   | psi                      |
| CO <sub>2</sub>                       | CO   | ppm  | CO/CO <sub>2</sub> ratio |
| F.G.T.                                | °C   | Flue pressure:   |                          |
| Comments:                             |  |  |                          |
| Signature:                            |  |  |                          |

|                                       |  |  |                          |
|---------------------------------------|--|--|--------------------------|
| <b>Service 7</b>                      |  | Date:  |                          |
| Engineer's name:                      |  |  |                          |
| Company name:                         |  |  |                          |
| Telephone number:                     |  |  |                          |
| Registration number:                  |  |  |                          |
| Fire valve inspected (rated to 85 °C) |  | Yes <input type="checkbox"/> No <input type="checkbox"/> |                          |
| Nozzle changed?                       | Yes <input type="checkbox"/> No <input type="checkbox"/> | Pump pressure:   | psi                      |
| CO <sub>2</sub>                       | CO   | ppm  | CO/CO <sub>2</sub> ratio |
| F.G.T.                                | °C   | Flue pressure:   |                          |
| Comments:                             |  |  |                          |
| Signature:                            |  |  |                          |

|                                       |  |  |                          |
|---------------------------------------|--|--|--------------------------|
| <b>Service 9</b>                      |  | Date:  |                          |
| Engineer's name:                      |  |  |                          |
| Company name:                         |  |  |                          |
| Telephone number:                     |  |  |                          |
| Registration number:                  |  |  |                          |
| Fire valve inspected (rated to 85 °C) |  | Yes <input type="checkbox"/> No <input type="checkbox"/> |                          |
| Nozzle changed?                       | Yes <input type="checkbox"/> No <input type="checkbox"/> | Pump pressure:   | psi                      |
| CO <sub>2</sub>                       | CO   | ppm  | CO/CO <sub>2</sub> ratio |
| F.G.T.                                | °C   | Flue pressure:   |                          |
| Comments:                             |  |  |                          |
| Signature:                            |  |  |                          |

|                                       |  |  |                          |
|---------------------------------------|--|--|--------------------------|
| <b>Service 2</b>                      |  | Date:  |                          |
| Engineer's name:                      |  |  |                          |
| Company name:                         |  |  |                          |
| Telephone number:                     |  |  |                          |
| Registration number:                  |  |  |                          |
| Fire valve inspected (rated to 85 °C) |  | Yes <input type="checkbox"/> No <input type="checkbox"/> |                          |
| Nozzle changed?                       | Yes <input type="checkbox"/> No <input type="checkbox"/> | Pump pressure:   | psi                      |
| CO <sub>2</sub>                       | CO   | ppm  | CO/CO <sub>2</sub> ratio |
| F.G.T.                                | °C   | Flue pressure:   |                          |
| Comments:                             |  |  |                          |
| Signature:                            |  |  |                          |

|                                       |  |  |                          |
|---------------------------------------|--|--|--------------------------|
| <b>Service 4</b>                      |  | Date:  |                          |
| Engineer's name:                      |  |  |                          |
| Company name:                         |  |  |                          |
| Telephone number:                     |  |  |                          |
| Registration number:                  |  |  |                          |
| Fire valve inspected (rated to 85 °C) |  | Yes <input type="checkbox"/> No <input type="checkbox"/> |                          |
| Nozzle changed?                       | Yes <input type="checkbox"/> No <input type="checkbox"/> | Pump pressure:   | psi                      |
| CO <sub>2</sub>                       | CO   | ppm  | CO/CO <sub>2</sub> ratio |
| F.G.T.                                | °C   | Flue pressure:   |                          |
| Comments:                             |  |  |                          |
| Signature:                            |  |  |                          |

|                                       |  |  |                          |
|---------------------------------------|--|--|--------------------------|
| <b>Service 6</b>                      |  | Date:  |                          |
| Engineer's name:                      |  |  |                          |
| Company name:                         |  |  |                          |
| Telephone number:                     |  |  |                          |
| Registration number:                  |  |  |                          |
| Fire valve inspected (rated to 85 °C) |  | Yes <input type="checkbox"/> No <input type="checkbox"/> |                          |
| Nozzle changed?                       | Yes <input type="checkbox"/> No <input type="checkbox"/> | Pump pressure:   | psi                      |
| CO <sub>2</sub>                       | CO   | ppm  | CO/CO <sub>2</sub> ratio |
| F.G.T.                                | °C   | Flue pressure:   |                          |
| Comments:                             |  |  |                          |
| Signature:                            |  |  |                          |

|                                       |  |  |                          |
|---------------------------------------|--|--|--------------------------|
| <b>Service 8</b>                      |  | Date:  |                          |
| Engineer's name:                      |  |  |                          |
| Company name:                         |  |  |                          |
| Telephone number:                     |  |  |                          |
| Registration number:                  |  |  |                          |
| Fire valve inspected (rated to 85 °C) |  | Yes <input type="checkbox"/> No <input type="checkbox"/> |                          |
| Nozzle changed?                       | Yes <input type="checkbox"/> No <input type="checkbox"/> | Pump pressure:   | psi                      |
| CO <sub>2</sub>                       | CO   | ppm  | CO/CO <sub>2</sub> ratio |
| F.G.T.                                | °C   | Flue pressure:   |                          |
| Comments:                             |  |  |                          |
| Signature:                            |  |  |                          |

|                                       |  |  |                          |
|---------------------------------------|--|--|--------------------------|
| <b>Service 10</b>                     |  | Date:  |                          |
| Engineer's name:                      |  |  |                          |
| Company name:                         |  |  |                          |
| Telephone number:                     |  |  |                          |
| Registration number:                  |  |  |                          |
| Fire valve inspected (rated to 85 °C) |  | Yes <input type="checkbox"/> No <input type="checkbox"/> |                          |
| Nozzle changed?                       | Yes <input type="checkbox"/> No <input type="checkbox"/> | Pump pressure:   | psi                      |
| CO <sub>2</sub>                       | CO   | ppm  | CO/CO <sub>2</sub> ratio |
| F.G.T.                                | °C   | Flue pressure:   |                          |
| Comments:                             |  |  |                          |
| Signature:                            |  |  |                          |

## Notes

## Notes

## Notes

**If the boiler does not give complete satisfaction, before calling for a service engineer, the installer should check the following:**

**General checks**

1. Is there 230 V across the boiler live and neutral terminals?
2. Is the polarity correct? (230 V across live and earth, 0 V across neutral and earth).
3. Is the air bled from the primary system?
4. Is the air bled from the oil supply?
5. Is the flue sized and routed correctly?

**Boiler runs straight to lockout**

1. Has the oil line been purged of air?
2. Where an air eliminator is used in conjunction with a top feed oil tank the non-return valve, (if fitted), should be removed from the oil dip pipe.

**Boiler locks out at the start of a demand (Heating off over night for example)**

1. If an air eliminator is being used, check that there are no leaks that allow air to be pulled into the oil supply.
2. If a two pipe oil supply is being used, has a non-return valve been fitted to the inlet pipe? Refer to the instructions for guidelines.

**No domestic hot water**

1. Is the mains water in connected to the 15 mm isolation valve?
2. Is there a domestic hot water demand from the programmer and has the tank reached temperature?

**No domestic hot water (external programmer)**

3. Is there 230 V on LR for DHW (tap symbol)?
4. Refit link between 230V OUT and LR for DHW.  
If the DHW now operates correctly there is a problem with the external programmer and/or its wiring.

**No central heating**

1. Are both programmer and room thermostat on demand for central heating?
2. Is the room thermostat wired correctly?

**No central heating (external programmer)**

1. Is there 230 V on LR for Central Heating (radiator symbol)?
2. Refit link between 230V OUT and LR on the Central heating

If the Central Heating now operates correctly there is a problem with the external programmer and/or its wiring.



Under no circumstances must an appliance be left to operate with any control linked out or overridden.

**WORCESTER, BOSCH GROUP:**

|                    |               |
|--------------------|---------------|
| TECHNICAL SUPPORT: | 0330 123 3366 |
| APPOINTMENTS:      | 0330 123 9339 |
| SPARES:            | 0330 123 9779 |
| LITERATURE:        | 0330 123 9119 |
| TRAINING:          | 0330 123 0166 |
| SALES:             | 0330 123 9669 |

Worcester, Bosch Group  
Cotswold Way, Warndon, Worcester WR4 9SW.  
Tel. 0330 123 9559

Worcester, Bosch Group is a brand name of Bosch Thermotechnology Ltd.  
worcester-bosch.co.uk

6 721 843 980 (2022/01)

**WORCESTER**  
Bosch Group